# ROGUE<sup>™</sup> WALK-BEHIND SCRAPER OPERATING & SERVICE MANUAL





407170 Rev B

| TABLE  | OF CONTENTS  | 3   |
|--|--|---|
| GENE   | RAL INFORMATION  | 6   |
| C  | CONTACT INFORMATION  | 6   |
| 5  |  | 6   |
| F  | RESOURCES  | 6   |
| I  | NTENDED USE  | 7   |
| A  | ALLOWED ENVIRONMENTAL CONDITIONS   | 7   |
| Ν  | ACHINE SPECIFICATIONS  | 8   |
| E  | EXTENSION CORD SELECTION   | 8   |
| (  | GENERATOR SELECTION  | 8   |
| SAFE1  | Ύ  | . 10  |
| 5  | SAFETY FIRST!  | . 10  |
| E  | BEFORE OPERATION   | . 10  |
| E  | ELECTRICAL CORDS   | 11  |
| (  | DPERATING THE MACHINE  | . 12  |
| T  | RANSPORTING THE MACHINE  | . 13  |
| Ν  | /AINTENANCE  | . 14  |
| S  | SAFETY LABELS  | . 16  |
| масн   |  | 18  |
|  |  | 40  |
| UPER/  |  | . 19  |
| INITIA   |  | . 20  |
| I  |  | . 20  |
| I  | NSTALLING THE BLADE HOLDER   | . 20  |
|  |  |   |
| MACH   | INE OPERATION  | . 21  |
| MACH   | INE OPERATION  | <b>. 21</b><br>. 21   |
| MACH<br>/<br>/   | INE OPERATION<br>ADJUSTING THE HANDLE<br>ADJUSTING THE WHEEL SCRAPERS  | <b>. 21</b><br>. 21<br>. 21   |
| <b>MACH</b><br>/<br>/<br>/   | INE OPERATION<br>ADJUSTING THE HANDLE<br>ADJUSTING THE WHEEL SCRAPERS<br>VEIGHTS   | . <b>21</b><br>. 21<br>. 21<br>. 22   |
| <b>MACH</b><br>/<br>/<br>V   | INE OPERATION<br>ADJUSTING THE HANDLE<br>ADJUSTING THE WHEEL SCRAPERS<br>VEIGHTS<br>Removing Front Weight  | <b>. 21</b><br>. 21<br>. 21<br>. 22<br>. 22   |
| MACH<br>/<br>/<br>V  | INE OPERATION.<br>ADJUSTING THE HANDLE.<br>ADJUSTING THE WHEEL SCRAPERS.<br>VEIGHTS.<br>Removing Front Weight.<br>Removing Middle Weights.   | . 21<br>. 21<br>. 21<br>. 22<br>. 22<br>. 23  |
| MACH<br>/<br>/<br>V  | INE OPERATION  | . 21<br>. 21<br>. 21<br>. 22<br>. 22<br>. 23<br>. 23  |
| MACH<br>/<br>/<br>V  | INE OPERATION.<br>ADJUSTING THE HANDLE.<br>ADJUSTING THE WHEEL SCRAPERS.<br>VEIGHTS<br>Removing Front Weight.<br>Removing Middle Weights.<br>Removing/Adjusting Slide Weights.<br>VHEEL MODES.   | . 21<br>. 21<br>. 22<br>. 22<br>. 23<br>. 23<br>. 23<br>. 24  |
| MACH<br>/<br>/<br>V  | INE OPERATION.<br>ADJUSTING THE HANDLE.<br>ADJUSTING THE WHEEL SCRAPERS.<br>VEIGHTS.<br>Removing Front Weight.<br>Removing Middle Weights.<br>Removing/Adjusting Slide Weights.<br>VHEEL MODES.<br>Disengaging Wheels.   | . 21<br>. 21<br>. 22<br>. 22<br>. 22<br>. 23<br>. 23<br>. 24<br>. 24  |
| <b>MACH</b><br>/<br>/<br>/<br>/  | INE OPERATION  | . 21<br>. 21<br>. 22<br>. 22<br>. 23<br>. 23<br>. 23<br>. 24<br>. 24<br>. 24  |
| MACH<br>/<br>/<br>V  | INE OPERATION.<br>ADJUSTING THE HANDLE.<br>ADJUSTING THE WHEEL SCRAPERS.<br>VEIGHTS  | . 21<br>. 21<br>. 22<br>. 22<br>. 23<br>. 23<br>. 23<br>. 24<br>. 24<br>. 24<br>. 24  |
| MACH<br>/<br>/<br>V<br>V   | INE OPERATION  | . 21<br>. 21<br>. 22<br>. 22<br>. 23<br>. 23<br>. 23<br>. 23<br>. 24<br>. 24<br>. 24<br>. 24<br>. 24<br>. 25  |
| MACH<br>/<br>/<br>V<br>V<br>V  | INE OPERATION  | . 21<br>. 21<br>. 22<br>. 22<br>. 22<br>. 23<br>. 23<br>. 23<br>. 24<br>. 24<br>. 24<br>. 24<br>. 25<br>. 25  |
| MACH<br>/<br>/<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V        | INE OPERATION<br>ADJUSTING THE HANDLE<br>ADJUSTING THE WHEEL SCRAPERS<br>VEIGHTS<br>Removing Front Weight<br>Removing Middle Weights<br>Removing/Adjusting Slide Weights<br>VHEEL MODES.<br>Disengaging Wheels<br>Engaging Wheels<br>IOBSITE EXPECTATIONS.<br>PREPARING FOR OPERATION<br>STARTING THE MACHINE<br>STOPPING THE MACHINE  | . 21<br>. 21<br>. 22<br>. 22<br>. 23<br>. 23<br>. 24<br>. 24<br>. 24<br>. 24<br>. 24<br>. 25<br>. 25  |
| MACH<br>/<br>/<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V        | INE OPERATION  | . 21<br>. 21<br>. 22<br>. 22<br>. 22<br>. 23<br>. 23<br>. 23<br>. 23<br>. 24<br>. 24<br>. 24<br>. 24<br>. 25<br>. 25<br>. 25  |
| <b>MACH</b><br><i>J</i><br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>C<br>C                                       | INE OPERATION  | <b>. 21</b><br>. 21<br>. 22<br>. 22<br>. 22<br>. 23<br>. 23<br>. 23<br>. 23<br>. 24<br>. 24<br>. 24<br>. 24<br>. 24<br>. 25<br>. 25<br>. 25<br>. 25<br>. 26   |
| <b>MACH</b><br>/<br>/<br>/<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V | INE OPERATION  | <b>. 21</b><br>. 21<br>. 22<br>. 22<br>. 22<br>. 23<br>. 24<br>. 24<br>. 24<br>. 24<br>. 24<br>. 25<br>. 25<br>. 25<br>. 25<br>. 26<br>. 26   |
| <b>MACH</b><br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/ | INE OPERATION  | <b>. 21</b><br>. 21<br>. 22<br>. 22<br>. 23<br>. 23<br>. 24<br>. 24<br>. 24<br>. 24<br>. 25<br>. 25<br>. 25<br>. 25<br>. 26<br>. 27   |
| <b>MACH</b><br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/ | INE OPERATION<br>ADJUSTING THE HANDLE.<br>ADJUSTING THE WHEEL SCRAPERS.<br>VEIGHTS.<br>Removing Front Weight<br>Removing Middle Weights.<br>Removing/Adjusting Slide Weights.<br>VHEEL MODES<br>Disengaging Wheels.<br>Engaging Wheels.<br>Engaging Wheels.<br>PREPARING FOR OPERATION.<br>STARTING THE MACHINE.<br>STOPPING THE MACHINE.<br>STOPPING THE MACHINE.<br>AFTER OPERATION<br>DRIVING THE MACHINE.<br>Left-Hand Preference.<br>Right-Hand Preference.<br>CHANGING THE BLADE HOLDER  | <b>.</b> 21<br>. 21<br>. 22<br>. 22<br>. 23<br>. 23<br>. 24<br>. 24<br>. 24<br>. 24<br>. 24<br>. 25<br>. 25<br>. 25<br>. 25<br>. 26<br>. 27<br>. 28   |
| MACH<br>/<br>/<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V        | INE OPERATION  | <b>21</b><br>221<br>222<br>223<br>23<br>23<br>24<br>24<br>24<br>24<br>24<br>25<br>25<br>25<br>25<br>25<br>25<br>25<br>26<br>26<br>27<br>28<br>27<br>29  |
| MACH<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/                                      | INE OPERATION<br>ADJUSTING THE HANDLE.<br>ADJUSTING THE WHEEL SCRAPERS   | <b>21</b><br>22<br>22<br>22<br>23<br>23<br>24<br>24<br>24<br>24<br>24<br>24<br>25<br>25<br>25<br>25<br>25<br>25<br>25<br>25<br>25<br>25<br>25<br>25<br>25   |
| <b>MACH</b><br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/                               | INE OPERATION<br>ADJUSTING THE HANDLE<br>ADJUSTING THE WHEEL SCRAPERS<br>VEIGHTS<br>Removing Front Weight<br>Removing Middle Weights<br>Removing/Adjusting Slide Weights<br>WHEEL MODES.<br>Disengaging Wheels.<br>Engaging Wheels.<br>Engaging Wheels.<br>OBSITE EXPECTATIONS<br>PREPARING FOR OPERATION<br>STARTING THE MACHINE<br>STOPPING THE MACHINE<br>STOPPING THE MACHINE<br>AFTER OPERATION<br>PREVANG THE MACHINE<br>AFTER OPERATION<br>STOPPING THE BLADE HOLDER<br>CHANGING THE BLADE HOLDER<br>Blade Setup   | <b>21</b><br>22<br>22<br>22<br>23<br>23<br>24<br>24<br>24<br>24<br>24<br>24<br>25<br>25<br>25<br>25<br>25<br>25<br>25<br>26<br>27<br>28<br>20<br>27<br>28<br>20<br>20<br>20<br>20<br>20<br>20<br>20<br>20<br>20<br>20<br>20<br>20<br>20 |
| <b>MACH</b><br>/<br>/<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V<br>V | INE OPERATION<br>ADJUSTING THE HANDLE<br>ADJUSTING THE WHEEL SCRAPERS<br>VEIGHTS<br>Removing Front Weight<br>Removing Middle Weights<br>Removing/Adjusting Slide Weights<br>VHEEL MODES<br>Disengaging Wheels<br>Engaging Wheels<br>OBSITE EXPECTATIONS<br>PREPARING FOR OPERATION<br>STARTING THE MACHINE<br>STOPPING THE MACHINE<br>STOPPING THE MACHINE<br>FTER OPERATION<br>DRIVING THE MACHINE<br>Left-Hand Preference<br>Right-Hand Preferenc | <b>21</b><br>21<br>22<br>22<br>22<br>23<br>23<br>24<br>24<br>24<br>24<br>24<br>24<br>25<br>25<br>25<br>25<br>25<br>25<br>25<br>25<br>26<br>27<br>28<br>29<br>30<br>30<br>30   |
| MACH<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/<br>/                                 | INE OPERATION<br>ADJUSTING THE HANDLE<br>ADJUSTING THE WHEEL SCRAPERS<br>VEIGHTS<br>Removing Front Weight<br>Removing Middle Weights<br>Removing Adjusting Slide Weights<br>VHEEL MODES<br>Disengaging Wheels<br>Engaging Wheels<br>Engaging Wheels<br>OBSITE EXPECTATIONS<br>PREPARING FOR OPERATION<br>STARTING THE MACHINE<br>STOPPING THE MACHINE<br>STOPPING THE MACHINE<br>FTER OPERATION<br>DRIVING THE MACHINE<br>Engint-Hand Preference<br>Right-Hand Preference<br>Right-Hand Preference<br>Right-Hand Preference<br>Right-Hand Preference<br>CHANGING THE BLADE HOLDER<br>CHANGING THE BLADE HOLDER<br>Blade Setup<br>Self-Scoring Blades<br>APPLICATIONS   | <b>21</b><br>21<br>22<br>22<br>22<br>23<br>23<br>24<br>24<br>24<br>24<br>24<br>24<br>25<br>25<br>25<br>25<br>25<br>25<br>25<br>25<br>25<br>26<br>27<br>28<br>29<br>30<br>30<br>30<br>30<br>31   |

## **Table of Contents**

| Ceramic   31     Direct-Glued Carpet.   31     Wood   31     Thin Coatings.   31     Re-Scrape.   31     Subfloor Surfaces   31     Glued Hardwood Flooring.   31     Wood   31     Gued Hardwood Flooring.   31     Concrete   31     Concrete   32     TRANSPORTING THE MACHINE   32     TRANSPORT WHEELS.   32     VEHICLE WITH POWER LIFTGATE   33     VEHICLE WITH POWER LIFTGATE   34     Ramp Unloading.   34     Ramp Loading.   34     Ramp Unloading.   34     MAINTENANCE SCHEDULE   38     MAINTENANCE SCHEDULE   38     MAINTENANCE SCHEDULE   38     REASSEMBLYING COMPONENTS   38     REMOVING THE HOOD   39     Lanyard Kill Switch   39  <   | Pure Vinyl Rubber Tile                      |    |
|--|---|----|
| Direct-Glued Carpet  | Ceramic                                     |    |
| Wood   31     Thin Coatings   31     Re-Scrape   31     Subfloor Surfaces   31     Glued Hardwood Flooring   31     Wood   31     Concrete   31     Gypcrete and Soft-Poured Flooring   31     Gypcrete and Soft-Poured Flooring   31     TRANSPORT WHEELS   32     TRANSPORT WHEELS   32     VEHICLE WITH POWER LIFTGATE   33     VEHICLE WITH RAMP   34     Ramp Loading   34     Ramp Loading   34     Ramp Unloading   34     HOISTING   35     MAINTENANCE SCHEDULE   38     MAINTENANCE SCHEDULE   38     REASSEMELYING COMPONENTS   38     REASSEMELYING COMPONENTS   39     CLEANING DEERIS BUILDUP   39     TESTING THE PADS AND LINERS.   41     NISPECTING FOR DAMAGE   39     CLEANING DEERIS BUILDUP   39     TESTING THE PADS AND LINERS.   41     CLEANING THE PADS AND LINERS.   41     CLEANING THE PADS AND LINERS.   42   | Direct-Glued Carpet                         |    |
| Thin Coatings.   31     Re-Sorape.   31     Subfloor Surfaces   31     Glued Hardwood Flooring.   31     Wood   31     Concrete.   31     Gypcrete and Soft-Poured Flooring.   31     TRANSPORTING THE MACHINE.   32     TRANSPORTING THE MACHINE.   32     VEHICLE WITH RAMP.   34     Ramp Loading.   34     Ramp Unloading.   34     HOISTING   35     TRANSPORT POLES (OPTIONAL).   36     MAINTENANCE   38     MAINTENANCE   38     REASSEMBLYING COMPONENTS   38     REMOVING THE HOOD   39     INSPECTING FOR DAMAGE.   39     CLEANING DEBRIS BUILDUP   39     TESTING THE SACENT CIRCUIT.   40     INSPECTING THE PADS AND LINERS.   41     ISOLATORS AND CUTTING HEAD BEARING.   42     Removing Replacing the Cutting Head Bearing.   42     Removing Replacing the Cutting Head Bearing.   42     Removing Meel   45     REMOVING/RELACING THE HANDLE   44     CLEARING GO   | Wood  |    |
| Re-Scrape   31     Subfloor Surfaces   31     Glued Hardwood Flooring   31     Wood   31     Concrete   31     Gypcrete and Soft-Poured Flooring   31     TRANSPORTING THE MACHINE   32     TRANSPORT WHEELS   32     VEHICLE WITH POWER LIFTGATE   33     VEHICLE WITH POWER LIFTGATE   34     Ramp Loading   34     ROBING   34     RANSPORT POLES (OPTIONAL)   35     TRANSPORT POLES (OPTIONAL)   36     MAINTENANCE   38     MAINTENANCE SCHEDULE   38     REASEMBLYING COMPONENTS   38     REMOVING THE HOOD   39     INSPECTING FOR DAMAGE   39     CLEANING DEBRIS BUILDUP   39     TESTING THE SAFETY CIRCUIT   39     Emergency Stop Switch   39     Lanyard Kill Switch   39     SUCLANING THE COUPLING FLANGES   41     CLEANING THE COUPLING FLANGES   41     CLEANING THE COUPLING FLANGES   41     CLEANING THE COUPLING FLANGES   42     Removing/Replacing the Bloato   | Thin Coatings                               |    |
| Subflors Surfaces   31     Glued Hardwood Flooring   31     Wood   31     Concrete   31     Gypcrete and Soft-Poured Flooring   31     TRANSPORTING THE MACHINE   32     TRANSPORT WHEELS   32     VEHICLE WITH POWER LIFTGATE   33     VEHICLE WITH PAMP   34     Ramp Loading   34     Ramp Unloading   34     HANSPORT POLES (OPTIONAL)   35     TRANSPORT POLES (OPTIONAL)   36     MAINTENANCE   38     MAINTENANCE   38     MAINTENANCE   38     REASSEMBLYING COMPONENTS   38     REMOVING THE HOOD   39     INSPECTING FOR DAMAGE   39     CLEANING DEBRIS BUILDUP   39     Emergency Slop Switch   39     Emergency Slop Switch   39     LINSPECTING THE PADS AND LINERS   41     ISOLATORS AND CUTTING HEAD BEARING   42     Removing/Replacing the Cutting Head Bearing   42     Removing/Replacing the Solators   42     Removing/Replacing the Solators   42     Removing   | Re-Scrape                                   |    |
| Glued Hardwood Flooring   31     Wood  | Subfloor Surfaces                           |    |
| Wood.   31     Concrete.   31     Gypcrete and Soft-Poured Flooring.   31     TRANSPORT ING THE MACHINE.   32     TRANSPORT WHEELS.   32     VEHICLE WITH POWER LIFTGATE.   33     VEHICLE WITH RAMP.   34     Ramp Loading.   34     Ramp Unloading.   34     HOISTING   35     TRANSPORT POLES (OPTIONAL).   36     MAINTENANCE   38     MAINTENANCE   38     REASSEMBLING COMPONENTS   38     REMOVING THE HOOD   39     INSPECTING FOR DAMAGE   39     CLEANING DEBRIS BUILDUP   39     TESTING THE SAPETY CIRCUIT.   39     Emergency Stop Switch.   39     Lanyard Kill Switch   39     LARON  | Glued Hardwood Flooring                     |    |
| Concrete   | Wood  |    |
| Gypcrete and Soft-Poured Flooring   31     TRANSPORT WHE MACHINE   32     TRANSPORT WHELLS   32     VEHICLE WITH POWER LIFTGATE   33     VEHICLE WITH POWER LIFTGATE   34     Ramp Loading   34     Ramp Loading   34     Ramp Loading   34     Ramp Loading   34     MAINTENANCE   35     MAINTENANCE SCHEDULE   38     MAINTENANCE SCHEDULE   38     REMOVING THE HOOD   39     INSPECTING FOR DAMAGE   39     CLEANING DEBRIS BUILDUP   39     Emergency Stop Switch   39     Lanyard Kill Switch   39     Lanyard Kill Switch   39     LSPECTING THE PADS AND LINERS   41     CLEANING THE COUPLING FLANGES   41     INSPECTING THE PADS AND LINERS   41     INSPECTING GREASING THE BLADE BARING   42     Removing/Replacing the Isolators  | Concrete                                    |    |
| TRANSPORTING THE MACHINE.   32     TRANSPORT WHEELS.   32     VEHICLE WITH POWER LIFTGATE.   33     VEHICLE WITH RAMP   34     Ramp Loading   34     Ramp Unloading.   34     HOISTING   35     TRANSPORT POLES (OPTIONAL)   36     MAINTENANCE   38     MAINTENANCE   38     MAINTENANCE SCHEDULE   38     REASSEMBLYING COMPONENTS   38     REASSEMBLYING COMPONENTS   38     RECOVING THE HOOD   39     INSPECTING FOR DAMAGE   39     CLEANING DEBRIS BUILDUP   39     TESTING THE SAFETY CIRCUIT   39     Emergency Stop Switch.   39     Lanyard KII Switch.   39     ISOLATORS AND CUTTING HEAD BEARING   41     ISOLATORS AND CUTTING HEAD BEARING   42     Inspection   42     Removing/Replacing the Cuting Head Bearing.   42     INSPECTING/GREASING THE BLADE ANOLE LINKAGE   44     CLEANING THE BLADE ANOLE LINKAGE   44     REMOVING/REPLACING THE WHEELS.   45     Removing/Replacing the Usolators   <   | Gypcrete and Soft-Poured Flooring           |    |
| TRANSPORT WHEELS.   32     VEHICLE WITH POWER LIFTGATE   33     VEHICLE WITH POWER LIFTGATE   34     Ramp Loading   34     Ramp Loading   34     Ramp Loading   34     Ramp Loading   34     HOISTING   35     TRANSPORT POLES (OPTIONAL)   36     MAINTENANCE   38     MAINTENANCE SCHEDULE   38     REASESEMBLYING COMPONENTS   38     REMOVING THE HOOD   39     INSPECTING FOR DAMAGE   39     INSPECTING THE SAFETY CIRCUIT   39     Emergency Stop Switch   39     INSPECTING THE SAFETY CIRCUIT   39     Lenyard Kill Switch   39     INSPECTING THE PADS AND LINERS   41     ISOLATORS AND CUTTING HEAD BEARING   42     Inspection   42     Removal and Replacement   42     Removing/Replacing the Uting Head Bearing   42     Removing/Replacing the Isolators   42     Removing/Replacing the Isolators   42     Removing/Replacing the WHEELS   44     RELECTING/GREALING THE WHEELS   45 <th>TRANSPORTING THE MACHINE</th> <th>32</th>                   | TRANSPORTING THE MACHINE                    | 32 |
| VEHICLE WITH POWER LIFTGATE   33     VEHICLE WITH RAMP   34     Ramp Loading   34     Ramp Unloading   34     HOISTING   35     TRANSPORT POLES (OPTIONAL)   36     MAINTENANCE   38     MAINTENANCE   38     REASSEMELYING COMPONENTS   38     REMOVING THE HOOD   39     INSPECTING FOR DAMAGE   39     CLEANING DEBRIS BUILDUP   39     TESTING THE SAFETY CIRCUIT   39     Lanyard Kill Switch   39     Lanyard Kill Switch   39     INSPECTING THE PADS AND LINERS.   41     CLEANING THE COUPLING FLANGES   41     ISLATORS AND CUTTING HEAD BEARING   42     Removing/Replacing the Sulting Head Bearing.   42     Removing/Replacing the Cutting Head Bearing.   42     REMOVING/REPLACING THE BLADE ANGLE LINKAGE   44     REMOVING/REPLACING THE WHEELS   45     Removing/Replacing the Cutting Head Bearing.   42     Removing/Replacing the BLADE ANGLE LINKAGE   44     REMOVING/REPLACING THE WHEELS   45     Renoving/Replacing the BLADE ANGLE LINKAGE | TRANSPORT WHEFI S                           | 32 |
| VEHICLE WITH RAMP   34     Ramp Loading   34     Ramp Unloading   34     HOISTING   35     TRANSPORT POLES (OPTIONAL)   36     MAINTENANCE   38     MAINTENANCE SCHEDULE   38     REASSEMBLYING COMPONENTS   38     REMOVING THE HOOD   39     INSPECTING FOR DAMAGE   39     CLEANING DEBRIS BUILDUP   39     TESTING THE SAFETY CIRCUIT   39     Emergency Stop Switch   39     Lanyard Kill Switch   39     TESTING THE COUPLING FLANGES   41     CLEANING THE COUPLING FLANGES   41     ISOLATORS AND CUTTING HEAD BEARING   42     Inspection   42     Removing/Replacing the Cutting Head Bearing   42     Removing/Replacing the Cutting Head Bearing   42     Removing/Replacing the Isolators   42     Removing/Replacing the Solators   42     Removing Wheel   45     Removing Wheel   45     Removing Handle   46     Reinstalling Handle   46     MAUUSTING HANDLE RELEASE LEVER   47   | VEHICLE WITH POWER LIFTGATE                 | 33 |
| Ramp Loading   34     Ramp Unloading   34     HOISTING   35     TRANSPORT POLES (OPTIONAL)   36     MAINTENANCE   38     MAINTENANCE SCHEDULE   38     REASSEMBLYING COMPONENTS   38     REMOVING THE HOOD   39     INSPECTING FOR DAMAGE   39     CLEANING DEBRIS BUILDUP   39     TESTING THE SAFETY CIRCUIT   39     Emergency Stop Switch   39     Lanyard Kill Switch   39     INSPECTING THE PADS AND LINERS   41     CLEANING THE COUND FAULT CIRCUIT   40     INSPECTING THE PADS AND LINERS   41     LINSPECTING THE COUPLING FLANGES   41     ISOLATORS AND CUTTING HEAD BEARING   42     Removing/Replacing the Cutting Head Bearing   42     Removing/Replacing the Cutting Head Bearing   42     Removing/Replacing the Loaders   44     REMOVING/REPLACING THE WHEELS   45     Removing Wheel   45     Removing Handle   46     Reinstalling Handle   46     ADJUSTING HANDLE RELEASE LEVER   47     ADJUSTING HAND                                      | VEHICLE WITH RAMP                           | 34 |
| Ramp Unioading   34     HOISTING   35     TRANSPORT POLES (OPTIONAL)   36     MAINTENANCE   38     MAINTENANCE SCHEDULE   38     REASSEMBLYING COMPONENTS   38     REMOVING THE HOOD   39     INSPECTING FOR DAMAGE   39     CLEANING DEBRIS BUILDUP   39     TESTING THE SAFETY CIRCUIT   39     Emergency Stop Switch   39     Lanyard Kill Switch   39     TESTING THE GROUND FAULT CIRCUIT   40     INSPECTING THE PADS AND LINERS   41     CLEANING THE COUPLING FLANGES   41     ISOLATORS AND CUTTING HEAD BEARING   42     Inspection   42     Removial and Replacement   42     Removing/Replacing the Cutting Head Bearing   42     Removing/Replacing the Isolators   42     Removing/Replacing the Isolators   44     REMOVING/REPLACING THE WHEELS   45     Removing Wheel   45     Removing Handle   46     Reinstalling Handle   46     Reinstalling Handle   46     Reinstalling Handle   46   | Ramp Loading                                | 34 |
| HOISTING   35     TRANSPORT POLES (OPTIONAL)   36     MAINTENANCE   38     MAINTENANCE SCHEDULE   38     REASSEMBLYING COMPONENTS   38     REMOVING THE HOOD   39     INSPECTING FOR DAMAGE   39     CLEANING DEBRIS BUILDUP   39     TESTING THE SAFETY CIRCUIT   39     Emergency Stop Switch   39     Lanyard Kill Switch   39     TESTING THE GROUND FAULT CIRCUIT   40     INSPECTING THE PADS AND LINERS   41     CLEANING THE COUPLING FLANGES   41     ISOLATORS AND CUTTING HEAD BEARING   42     Inspection   42     Removing/Replacing the Cutting Head Bearing   42     Removing/Replacing the Solators   42     INSPECTING GREASING THE BLADE ANGLE LINKAGE   44     REMOVING/REPLACING THE WHEELS   45     Removing Wheel   45     Removing Hendle   46     Removing Hendle   46     Removing Handle   46     Removing Hendle   45     REMOVING/REINSTALLING THE HANDLE   47     ADJUSTING HANDLE PIVOT  | Ramp Unloading                              |    |
| TRANSPORT POLES (OPTIONAL)   36     MAINTENANCE   38     MAINTENANCE SCHEDULE   38     REASSEMBLYING COMPONENTS   38     REASSEMBLYING COMPONENTS   39     INSPECTING FOR DAMAGE   39     INSPECTING FOR DAMAGE   39     CLEANING DEBRIS BUILDUP   39     TESTING THE SAFETY CIRCUIT   39     Emergency Stop Switch   39     Lanyard Kill Switch   39     TESTING THE GROUND FAULT CIRCUIT   40     INSPECTING THE OUPLING FLANGES   41     CLEANING THE COUPLING FLANGES   41     ISOLATORS AND CUTTING HEAD BEARING   42     Inspection   42     Removing/Replacing the Cutting Head Bearing   42     Removing/Replacing the Isolators   42     INSPECTING THE BLADE ANGLE LINKAGE   44     REMOVING/REPLACING THE WHEELS   45     Removing Wheel   45     Replacing Wheel   45     Removing Handle   46     Reinstalling Handle   46     Reinstalling Handle   46     Reinstalling Handle   46     Reinstalling Handle  | HOISTING                                    |    |
| MAINTENANCE   38     MAINTENANCE SCHEDULE   38     REASSEMBLYING COMPONENTS   38     REMOVING THE HOOD   39     INSPECTING FOR DAMAGE   39     CLEANING DEBRIS BUILDUP   39     TESTING THE SAFETY CIRCUIT   39     Lanyard Kill Switch   39     Lanyard Kill Switch   39     TESTING THE GROUND FAULT CIRCUIT   40     INSPECTING THE PADS AND LINERS   41     CLEANING THE COUPLING FLANGES   41     CLEANING THE COUPLING FLANGES   41     ISOLATORS AND CUTTING HEAD BEARING   42     Inspection   42     Removing/Replacing the Cutting Head Bearing   42     Removing/Replacing the Isolators   42     INSPECTING/GREASING THE BLADE ANGLE LINKAGE   44     CLEARING JAMS   44     REMOVING/REINSTALLING THE WHEELS   45     Removing Wheel   45     Removing Handle   46     RAUUSTING HANDLE PIVOT   47     ADJUSTING HANDLE PIVOT   47     ADJUSTING HANDLE PIVOT   47     ADJUSTING HANDLE RELEASE LEVER   47     ADJUS                                      | TRANSPORT POLES (OPTIONAL)                  |    |
| MAINTENANCE   36     MAINTENANCE   38     REASSEMBLYING COMPONENTS   38     REMOVING THE HOOD   39     INSPECTING FOR DAMAGE   39     CLEANING DEBRIS BUILDUP   39     TESTING THE SAFETY CIRCUIT   39     Emergency Stop Switch   39     Lanyard Kill Switch   39     TESTING THE GROUND FAULT CIRCUIT   40     INSPECTING THE PADS AND LINERS   41     CLEANING THE COUPLING FLANGES   41     ISOLATORS AND CUTTING HEAD BEARING   42     Inspection   42     Removing/Replacing the Cutting Head Bearing.   42     Removing/Replacing the Cutting Head Bearing.   42     INSPECTING/GREASING THE BLADE ANGLE LINKAGE   44     CLEARING JAMS.   44     REMOVING/REPLACING THE WHEELS   45     Removing Wheel   45     Removing Wheel   45     Removing Handle   46     Applacing Wheel   45     Removing Handle   46     ADJUSTING HANDLE PIVOT   47     ADJUSTING HANDLE RELEASE LEVER   47     ADJUSTING CONTROL HANDLE KNOBS                                      |   | 20 |
| MAINTENACE SCHEDULE   36     REASSEMBLYING COMPONENTS   38     REMOVING THE HOOD   39     INSPECTING FOR DAMAGE.   39     CLEANING DEBRIS BUILDUP   39     TESTING THE SAFETY CIRCUIT.   39     Lanyard Kill Switch   39     Lanyard Kill Switch   39     Lanyard Kill Switch   39     TESTING THE GROUND FAULT CIRCUIT.   40     INSPECTING THE COUPLING FLANGES.   41     CLEANING THE COUPLING FLANGES.   41     ISOLATORS AND CUTTING HEAD BEARING   42     Inspection   42     Removing/Replacing the Cutting Head Bearing.   42     Removing/Replacing the Solators   42     INSPECTING/GREASING THE BLADE ANGLE LINKAGE   44     CLEARING JAMS   44     REMOVING/REINSTALLING THE WHEELS   45     Removing Wheel   45     Removing Wheel   45     Removing Handle   46     Reinstalling HanDLE PIVOT   47   |   |    |
| NEASSEMBLTING CONFORENTS   36     REMOVING THE HOOD   39     INSPECTING FOR DAMAGE   39     CLEANING DEBRIS BUILDUP   39     TESTING THE SAFETY CIRCUIT   39     Lanyard Kill Switch   39     TESTING THE GROUND FAULT CIRCUIT   40     INSPECTING THE PADS AND LINERS.   41     CLEANING THE COUPLING FLANGES   41     ISOLATORS AND CUTTING HEAD BEARING   42     Inspection   42     Removal and Replacement   42     Removing/Replacing the Cutting Head Bearing.   42     Removing/Replacing the Isolators   42     INSPECTING/GREASING THE BLADE ANGLE LINKAGE   44     CLEARING JAMS   44     REMOVING/REPLACING THE WHEELS   45     Removing Wheel   45     Removing Handle   46     Removing Handle   46     Removing Handle   46     Removing Handle   47     ADJUSTING CONTROL HANDLE KVORS   47     ADJUSTING CONTROL HANDLE KNOBS   47     ADJUSTING CONTROL HANDLE KNOBS   47     ADJUSTING CONTROL HANDLE KNOBS   47                                    |   |    |
| NEWBOYNG THE NOOD   39     INSPECTING FOR DAMAGE   39     CLEANING DEBRIS BUILDUP   39     TESTING THE SAFETY CIRCUIT   39     Lanyard Kill Switch   39     TESTING THE GROUND FAULT CIRCUIT.   40     INSPECTING THE PADS AND LINERS.   41     CLEANING THE COUPLING FLANGES.   41     ISOLATORS AND CUTTING HEAD BEARING   42     Inspection   42     Removal and Replacement   42     Removing/Replacing the Cutting Head Bearing.   42     INSPECTING/GREASING THE BLADE ANGLE LINKAGE   44     CLEANING JAMS.   44     Removing/Replacing the Isolators   42     Removing/Replacing the Isolators   42     Removing Weel   45     Replacing Wheel   45     Removing Wheel   45     Removing Handle   46     Reinstalling Handle   46     ADJUSTING HANDLE RELEASE LEVER   47     ADJUSTING CONTROL HANDLE KNOBS   47     ADJUSTING CONTROL HANDLE KNOBS   47     ADJUSTING CONTROL HANDLE KNOBS   47     ADJUSTING HANDLE OF THE LINEAR ACTUATOR   48             |   |    |
| INSPECTING FOR SERIS BUILDUP   39     CLEANING DEBRIS BUILDUP   39     TESTING THE SAFETY CIRCUIT   39     Lanyard Kill Switch   39     Lanyard Kill Switch   39     TESTING THE GROUND FAULT CIRCUIT   40     INSPECTING THE PADS AND LINERS   41     CLEANING THE COUPLING FLANGES   41     ISOLATORS AND CUTTING HEAD BEARING   42     Inspection   42     Removal and Replacement   42     Removing/Replacing the Cutting Head Bearing   42     Removing/Replacing the Isolators   42     INSPECTING/GREASING THE BLADE ANGLE LINKAGE   44     CLEARING JAMS   44     REMOVING/REPLACING THE WHEELS   45     Replacing Wheel   45     Removing Wheel   45     Removing Handle   46     Removing Handle   46     ADJUSTING HANDLE PIVOT   47     ADJUSTING HANDLE RELEASE LEVER   47     ADJUSTING CONTROL HANDLE KNOBS   47     ADJUSTING HANDLE PIVOT   47     ADJUSTING THE UNEAR ACTUATOR   48     RESETTING THE ONBOARD CIRCUIT BREAKER   48 <                 |   |    |
| CLEANING DEBRIS DOILDOP   39     TESTING THE SAFETY CIRCUIT.   39     Emergency Stop Switch.   39     Lanyard Kill Switch   39     TESTING THE GROUND FAULT CIRCUIT.   40     INSPECTING THE PADS AND LINERS.   41     CLEANING THE COUPLING FLANGES.   41     ISOLATORS AND CUTTING HEAD BEARING   42     Inspection   42     Removial and Replacement.   42     Removing/Replacing the Cutting Head Bearing.   42     INSPECTING/GREASING THE BLADE ANGLE LINKAGE   44     CLEARING JAMS   44     REMOVING/REPLACING THE WHEELS   45     Removing Wheel   45     Replacing Wheel   45     Removing Handle   46     Reinstalling Handle   46     ADJUSTING HANDLE PIVOT   47     ADJUSTING HANDLE RELEASE LEVER   47     ADJUSTING CONTROL HANDLE KNOBS   47     MANUAL OVERRIDE OF THE LINEAR ACTUATOR   48     RESETTING THE ONBOARD CIRCUIT BREAKER   48   |   |    |
| Test fine SAPET For Uncommendation   39     Emergency Stop Switch.   39     Lanyard Kill Switch   39     TESTING THE GROUND FAULT CIRCUIT.   40     INSPECTING THE PADS AND LINERS.   41     CLEANING THE COUPLING FLANGES.   41     ISOLATORS AND CUTTING HEAD BEARING.   42     Inspection   42     Removial and Replacement   42     Removing/Replacing the Cutting Head Bearing.   42     Removing/Replacing the Isolators   42     INSPECTING/GREASING THE BLADE ANGLE LINKAGE   44     CLEARING JAMS   44     REMOVING/REPLACING THE WHEELS   45     Replacing Wheel   45     Replacing Wheel   45     Removing Handle   46     Reinstalling Handle   46     ADJUSTING HANDLE PIVOT   47     ADJUSTING HANDLE RELEASE LEVER   47     ADJUSTING ONTROL HANDLE KNOBS   47     MANUAL OVERRIDE OF THE LINEAR ACTUATOR   48     RESETTING THE ONBOARD CIRCUIT BREAKER   48   |   |    |
| Entrief gency stop Switch   39     Lanyard Kill Switch   39     TESTING THE GROUND FAULT CIRCUIT   40     INSPECTING THE PADS AND LINERS   41     CLEANING THE COUPLING FLANGES   41     ISOLATORS AND CUTTING HEAD BEARING   42     Inspection   42     Removal and Replacement   42     Removing/Replacing the Cutting Head Bearing   42     INSPECTING/GREASING THE BLADE ANGLE LINKAGE   44     CLEARING JAMS   44     REMOVING/REPLACING THE WHEELS   45     Removing Wheel   45     Replacing Wheel   45     Removing Handle   46     Removing Handle   46     ADJUSTING HANDLE RELEASE LEVER   47     ADJUSTING HANDLE RELEASE LEVER   47     ADJUSTING HANDLE RELEASE LEVER   47     ADJUSTING CONTROL HANDLE KNOBS   47     MANUAL OVERRIDE OF THE LINEAR ACTUATOR   48     RESETTING THE ONBOARD CIRCUIT BREAKER   48  | Emorgonov Ston Switch                       |    |
| TESTING THE GROUND FAULT CIRCUIT.   40     INSPECTING THE PADS AND LINERS.   41     CLEANING THE COUPLING FLANGES.   41     ISOLATORS AND CUTTING HEAD BEARING.   42     Inspection   42     Removial and Replacement   42     Removing/Replacing the Cutting Head Bearing.   42     Removing/Replacing the Isolators   42     INSPECTING/GREASING THE BLADE ANGLE LINKAGE   44     CLEARING JAMS.   44     REMOVING/REPLACING THE WHEELS   45     Removing Wheel   45     Removing Handle   46     Removing Handle   46     ADJUSTING HANDLE PIVOT   47     ADJUSTING HANDLE RELEASE LEVER   47     ADJUSTING CONTROL HANDLE KNOBS.   47     MANUAL OVERRIDE OF THE LINEAR ACTUATOR.   48     RESETTING THE ONBOARD CIRCUIT BREAKER   48  | Lanvard Kill Switch                         |    |
| INSPECTING THE PADS AND LINERS.   41     CLEANING THE COUPLING FLANGES.   41     ISOLATORS AND CUTTING HEAD BEARING   42     Inspection   42     Removal and Replacement   42     Removing/Replacing the Cutting Head Bearing   42     Removing/Replacing the Isolators   42     INSPECTING/GREASING THE BLADE ANGLE LINKAGE   44     CLEARING JAMS   44     REMOVING/REPLACING THE WHEELS   45     Removing Wheel   45     Removing Handle   46     Reinstalling Handle   46     ADJUSTING HANDLE PIVOT   47     ADJUSTING HANDLE RELEASE LEVER   47     ADJUSTING CONTROL HANDLE KNOBS   47     MANUAL OVERRIDE OF THE LINEAR ACTUATOR   48  |   |    |
| INST ECHNO THE COUPLING FLANGES.   41     ISOLATORS AND CUTTING HEAD BEARING   42     Inspection   42     Removal and Replacement   42     Removing/Replacing the Cutting Head Bearing.   42     Removing/Replacing the Isolators   42     INSPECTING/GREASING THE BLADE ANGLE LINKAGE   44     CLEARING JAMS.   44     REMOVING/REPLACING THE WHEELS   45     Removing Wheel   45     Removing Wheel   45     REMOVING/REINSTALLING THE HANDLE   46     Removing Handle   46     ADJUSTING HANDLE PIVOT   47     ADJUSTING CONTROL HANDLE KNOBS.   47     MANUAL OVERRIDE OF THE LINEAR ACTUATOR.   48  |   |    |
| ISOLATIORS AND CUTTING HEAD BEARING   42     Inspection   42     Removial and Replacement   42     Removing/Replacing the Cutting Head Bearing   42     Removing/Replacing the Isolators   42     INSPECTING/GREASING THE BLADE ANGLE LINKAGE   44     CLEARING JAMS   44     REMOVING/REPLACING THE WHEELS   45     Removing Wheel   45     Removing Handle   46     Removing Handle   46     ADJUSTING HANDLE PIVOT   47     ADJUSTING CONTROL HANDLE KNOBS   47     MANUAL OVERRIDE OF THE LINEAR ACTUATOR   48     RESETTING THE ONBOARD CIRCUIT BREAKER   48  |   |    |
| INSPECTION OF THE DELETING   42     Inspection   42     Removal and Replacement   42     Removing/Replacing the Cutting Head Bearing   42     Removing/Replacing the Isolators   42     INSPECTING/GREASING THE BLADE ANGLE LINKAGE   44     CLEARING JAMS   44     REMOVING/REPLACING THE WHEELS   45     Removing Wheel   45     Replacing Wheel   45     Removing Wheel   45     Removing Handle   46     Reinstalling Handle   46     ADJUSTING HANDLE PIVOT   47     ADJUSTING CONTROL HANDLE KNOBS   47     MANUAL OVERRIDE OF THE LINEAR ACTUATOR   48     RESETTING THE ONBOARD CIRCUIT BREAKER   48   | ISOLATORS AND CLITTING HEAD BEARING         |    |
| Removal and Replacement   42     Removing/Replacing the Cutting Head Bearing   42     Removing/Replacing the Isolators   42     INSPECTING/GREASING THE BLADE ANGLE LINKAGE   44     CLEARING JAMS   44     REMOVING/REPLACING THE WHEELS   45     Removing Wheel   45     Removing Wheel   45     Removing Handle   46     Reinstalling Handle   46     ADJUSTING HANDLE PIVOT   47     ADJUSTING CONTROL HANDLE KNOBS   47     MANUAL OVERRIDE OF THE LINEAR ACTUATOR   48     RESETTING THE ONBOARD CIRCUIT BREAKER   48  |   |    |
| Removing/Replacing the Cutting Head Bearing.   42     Removing/Replacing the Isolators   42     INSPECTING/GREASING THE BLADE ANGLE LINKAGE   44     CLEARING JAMS.   44     REMOVING/REPLACING THE WHEELS   45     Removing Wheel   45     Replacing Wheel   45     Removing Handle   46     Reinstalling Handle   46     ADJUSTING HANDLE PIVOT   47     ADJUSTING CONTROL HANDLE KNOBS   47     MANUAL OVERRIDE OF THE LINEAR ACTUATOR   48     RESETTING THE ONBOARD CIRCUIT BREAKER   48  | Removal and Renlacement                     |    |
| Removing/Replacing the loolators   42     INSPECTING/GREASING THE BLADE ANGLE LINKAGE   44     CLEARING JAMS   44     REMOVING/REPLACING THE WHEELS   45     Removing Wheel   45     Replacing Wheel   45     Removing Handle   46     Reinstalling Handle   46     ADJUSTING HANDLE PIVOT   47     ADJUSTING CONTROL HANDLE KNOBS   47     MANUAL OVERRIDE OF THE LINEAR ACTUATOR   48     RESETTING THE ONBOARD CIRCUIT BREAKER   48   | Removing/Replacing the Cutting Head Bearing | 42 |
| INSPECTING/GREASING THE BLADE ANGLE LINKAGE  | Removing/Replacing the Isolators            | 42 |
| CLEARING JAMS   44     REMOVING/REPLACING THE WHEELS   45     Removing Wheel   45     Replacing Wheel   45     Removing Handle   46     Reinstalling Handle   46     ADJUSTING HANDLE RELEASE LEVER   47     ADJUSTING CONTROL HANDLE KNOBS   47     MANUAL OVERRIDE OF THE LINEAR ACTUATOR   48     RESETTING THE ONBOARD CIRCUIT BREAKER   48  | INSPECTING/GREASING THE BLADE ANGLE LINKAGE | 44 |
| REMOVING/REPLACING THE WHEELS   45     Removing Wheel   45     Replacing Wheel   45     REMOVING/REINSTALLING THE HANDLE   46     Removing Handle   46     Reinstalling Handle   46     ADJUSTING HANDLE PIVOT   47     ADJUSTING HANDLE RELEASE LEVER   47     ADJUSTING CONTROL HANDLE KNOBS   47     MANUAL OVERRIDE OF THE LINEAR ACTUATOR   48     RESETTING THE ONBOARD CIRCUIT BREAKER   48   | CLEARING JAMS                               | 44 |
| Removing Wheel   45     Replacing Wheel   45     REMOVING/REINSTALLING THE HANDLE   46     Removing Handle   46     Reinstalling Handle   46     ADJUSTING HANDLE PIVOT   47     ADJUSTING HANDLE RELEASE LEVER   47     ADJUSTING CONTROL HANDLE KNOBS   47     MANUAL OVERRIDE OF THE LINEAR ACTUATOR   48     RESETTING THE ONBOARD CIRCUIT BREAKER   48  | REMOVING/REPLACING THE WHEELS               | 45 |
| Replacing Wheel  | Removing Wheel                              | 45 |
| REMOVING/REINSTALLING THE HANDLE   | Replacing Wheel                             |    |
| Removing Handle   46     Reinstalling Handle   46     ADJUSTING HANDLE PIVOT   47     ADJUSTING HANDLE RELEASE LEVER   47     ADJUSTING CONTROL HANDLE KNOBS   47     MANUAL OVERRIDE OF THE LINEAR ACTUATOR   48     RESETTING THE ONBOARD CIRCUIT BREAKER   48   | REMOVING/REINSTALLING THE HANDLE            |    |
| Reinstalling Handle  | Removing Handle                             |    |
| ADJUSTING HANDLE PIVOT   | Reinstalling Handle                         |    |
| ADJUSTING HANDLE RELEASE LEVER   | ADJUSTING HANDLE PIVOT                      |    |
| ADJUSTING CONTROL HANDLE KNOBS   | ADJUSTING HANDLE RELEASE LEVER              |    |
| MANUAL OVERRIDE OF THE LINEAR ACTUATOR   | ADJUSTING CONTROL HANDLE KNOBS              |    |
| RESETTING THE ONBOARD CIRCUIT BREAKER  | MANUAL OVERRIDE OF THE LINEAR ACTUATOR      |    |
|  | RESETTING THE ONBOARD CIRCUIT BREAKER       |    |

## **Table of Contents**

| LONG TERM STORAGE                        |    |
|--|----|
| TROUBLESHOOTING                          |    |
| TROUBLESHOOTING GUIDE                    |    |
| FAULT CODES                              | 51 |
| PARTS LISTS                              | 52 |
| OVERALL MACHINE                          |    |
| POWER CORD 407141-XXXX                   | 53 |
| SCRAPER BASE ASSEMBLY 405055-XXX         | 54 |
| ORBITAL MOTOR ASSEMBLY 405057-XXX        | 55 |
| ECCENTRIC ASSEMBLY 407353                | 56 |
| CUTTING HEAD ASSEMBLY 405056             | 57 |
| ACTUATOR/LINKAGE ASSEMBLY 407359         | 58 |
| BRACKET ASSEMBLY 407364                  | 60 |
| CUTTING HEAD PLATE 407363                | 61 |
| DUAL DRIVE MOTORS ASSEMBLY 405071-XXX    |    |
| BOTTOM COVER 406687                      | 63 |
| TAIL ASSEMBLY 405751                     |    |
| POWER DISTRIBUTION PANEL ASSEMBLY 405251 |    |
| LIFTING BAR 406684                       | 67 |
| HANDLE ASSEMBLY 404863-XXX               |    |
| HOOD 406685-X                            | 74 |
| FRONT WEIGHT 405944-X                    | 75 |
| MIDDLE WEIGHT 406090                     |    |
| SLIDE WEIGHT 406062                      | 76 |
| WHEEL SCRAPERS 406686                    |    |
| TRANSPORT WHEELS 406633                  |    |
| TRANSPORT POLES (OPTIONAL) 408027        | 78 |
| WIRING DIAGRAMS                          | 80 |
| PRIMARY SYSTEMS (DIAGRAM 1)              | 80 |
| PRIMARY SYSTEMS (DIAGRAM 2)              | 81 |
| PRIMARY SYSTEMS (DIAGRAM 3)              | 82 |
| PAGE RESERVED FOR FUTURE USE             | 83 |
| CONTROL SYSTEMS (DIAGRAM 1)              |    |
| CONTROL SYSTEMS (DIAGRAM 2)              |    |
| CONTROL SYSTEMS (DIAGRAM 3)              |    |
| CONTROL SYSTEMS (DIAGRAM 4)              |    |

### **CONTACT INFORMATION**

Contact National Flooring Equipment (NFE) for customer support:

#### National Flooring Equipment, Inc.

9250 Xylon Avenue North Minneapolis, MN 55445 Tel: (800) 245-0267 Fax: (800) 648-7124 nationalequipmentdirect.com info@nationalequipment.com

### SERIAL NUMBER

When contacting NFE, always provide the serial number of the machine. The serial number label is located on the back of the machine.

### RESOURCES

Scan the QR code to access the manual, warranty and other resources for the machine. The QR code label is located on the back of the machine.



### INTENDED USE

The Rogue walk-behind scraper is used to remove existing material from the floor including linoleum, VCT, hardwood, ceramic tile, rubber-backed carpet, glued-down carpet, coatings, plastic floor coverings, foam, plastic droppings, parquet flooring, chewing gum, felt, accumulated grime, rubber and vinyl tile, epoxy, paint and adhesives. The machine is designed for indoor use and confined spaces in residential and commercial environments.

The machine is not designed for use outdoors or in wet environments. The machine must not be run on an incorrect electrical supply and must not be used outdoors, on a roof or as a ramming device.

Operators should have average mechanical abilities and the ability to lift 70 lbs. Maintenance personnel should be fully trained, have above average mechanical abilities and the ability to lift 70 lbs. Trainees should be supervised, have above average mechanical abilities and the ability to lift 70 lbs. Operators, maintenance personnel and trainees should read and understand the operating and service manual before operating or working on the machine.

### ALLOWED ENVIRONMENTAL CONDITIONS

The machine should be run in temperatures between 40°F-120°F (4°C-49°C) with relative humidity not above 95% to ensure correct operation.

Do not operate the machine in damp or wet locations, or in the presence of explosive or combustible atmospheres such as gaseous fumes, flammable materials and saw dust.

The machine may be operated in dusty conditions. The operator and other personnel in the proximity of the machine must wear adequate safety equipment including eye protection, ear protection, safety shoes, safety gloves, hard hat, high visibility safety vest and dust mask.

### **MACHINE SPECIFICATIONS**

|   |                                | ROGUE Scraper                   |
|---|--------------------------------|---------------------------------|
| Α | Width (slide weights forward)  | 19.4" (49 cm)                   |
| В | Width (slide weights rearward) | 22.1" (56 cm)                   |
| С | Length (handle forward)        | 41.4" (105 cm)                  |
| D | Length (handle back)           | 56.8" (144 cm)                  |
| Е | Height (handle forward)        | 25.3" (64 cm)                   |
| F | Height (handle vertical)       | 45.3" (115 cm)                  |
|   | Weight*                        | 472 lbs (214.1 kg)              |
|   | Weight (machine only)          | 295 lbs (133.8 kg)              |
|   | Forward Speed                  | 3-150 ft/min (.9- 45.7 m/min)   |
|   | Drive Motor Power (each)       | 1/3 HP (250W)                   |
|   | Orbital Motor Power            | 3/4 HP (550W)                   |
|   | Orbital Motor Speed            | 650-1900 rpm                    |
|   | Input Power                    | 100-240V, 50/60 Hz              |
|   | Amps                           | 15A                             |
|   | Max. Hand-Arm Vibration (HAV)  | 12.844 ± 1.532 m/s <sup>2</sup> |
|   | Sound Power Level              | 85.5 dBA                        |
|   | Sound Pressure                 | 79.7 dBA                        |
|   | Body Color                     | Silver Vein                     |

\*Includes removable weights and transport wheels.

### **EXTENSION CORD SELECTION**

| Input Power | Recommended Extension Cord Size* |
|-------------|----------------------------------|
| 100-130V    | 12 AWG (4 mm <sup>2</sup> )      |
| 200-240V    | 14 AWG (2.5 mm <sup>2</sup> )    |

\*Based on a maximum cord length of 150 ft (45 m), <10% voltage loss, data from the U.S. National Electrical Code Tables 400.5(A) & 400.5(B) and typical resistances for copper wire.

### **GENERATOR SELECTION**

Recommended Generator Rating\*: 5 kW

\*Rating is "Running Watts" or "Continuous Watts"-not "Peak Output".

### MACHINE SPECIFICATIONS (CONT'D)





## A SAFETY FIRST!

Look for the safety alert symbol. This symbol is used throughout the manual and on the labels of the machine to warn of the possibility of personal injury. Read these instructions carefully. It is essential that you read these instructions before you attempt to operate the machine.

|            | Identifies an immediate hazard which, if not avoided, will result in death or serious injury.   |
|------------|---|
|            | Identifies a potential hazard which, if not avoided, could result in death or serious injury.   |
|            | Identifies a potential hazard which, if not avoided, could result in minor or moderate injury and/or could result in damage to equipment. |
| IMPORTANT: | Indicates equipment or property damage could result if instructions are not followed.   |
| NOTE:      | Gives helpful information.  |

Read and understand this safety section carefully before operating the machine.

### **BEFORE OPERATION**

1. Carefully read and understand this manual before operating or servicing the machine. Keep the manual with the machine at all times. If your manual is lost or damaged, contact National Flooring Equipment (NFE) for a replacement.



- 2. Do not allow anyone to use this machine until they have been informed of the work to be done and they have read and understood this manual. Know your equipment and its limitations. Personnel must be properly trained before operating or servicing this machine.
- Safety labels carry important information. Obey the danger, warning and caution labels attached to the machine. If unreadable or missing, contact NFE for a replacement.

4. Dress properly and wear adequate safety equipment. The operator and any other personnel in the proximity of the machine must wear eye protection, ear protection, safety shoes, safety gloves, hard hat, high visibility safety vest and dust mask. Do not wear loose clothing as it could get caught in moving parts and cause injury.



- 5. Do not operate the machine when tired, distracted or under the influence of drugs, alcohol or any medication that may cause decreased control.
- 6. Scraping of concrete and other materials can generate harmful dust which can cause serious injury or illness such as respiratory disease. The operator and any by-standers should always wear a safety mask.



- 7. Check the surrounding area before using the machine.
  - Be aware of protrusions (stud anchors, rebar, threaded rod, etc.), cracks and expansion joints.
  - Check for buried pipes and cables.
  - Observe location of electrical supplies and extension cords. Do not allow cutting edge to come into contact with any electrical supply or extension cord.
- 8. Keep work area tidy and well-lit. A cluttered or dark work area could lead to accidents.
- 9. Keep cutting edges sharp and clean.
- 10.Make sure blades, blade holders and weights are securely mounted.
- 11. Make sure the control handles are dry, clean and free of oil and grease.
- 12. Make sure to use the proper electrical supply for the machine requirements to avoid the possibility of electric shock.
- 13. The electrical supply must be equipped with a proper circuit breaker.
- 14. Guard against electric shock.
  - Prevent bodily contact with grounded surfaces such as pipes, radiators, ranges and refrigerators.
  - When scoring or making cuts, always check the work area for hidden wires or pipes.

### **ELECTRICAL CORDS**

Electrical cords can be hazardous. Misuse can result in fire or death by electrical shock. Read carefully and follow all directions.



Always follow applicable electrical codes, standards and/ or regulations. Consult your local electrical authority or a licensed electrician before attempting to modify an electrical installation. Ensure that circuit and ground fault protection devices and all other safety equipment are functioning properly.

- 1. Ensure the cord is suitable for the application and location. If you are unsure about your cord type, consult a qualified electrical professional or electrician.
- Ground your equipment. The equipment must be plugged into an appropriate outlet, one which is properly installed and grounded in accordance with all codes and ordinances. Do NOT modify the plug provided with the equipment. Never remove the grounding prong from the plug.
- 3. Do not remove, bend or modify any metal prongs or pins of the plug. Modifications to power cords and/or plugs may result in injury and/or equipment damage.
- 4. Make sure both ends of the cord are fully seated.
- 5. Do not use excessive force to make connections.
- 6. Never unplug by pulling the cord from the outlet. Pull plug rather than cord to reduce the risk of damage.
- Regularly examine your extension cord and ensure it is in good electrical condition. Never use a damaged cord—either replace it or have it repaired by a qualified person.
- 8. Protect your extension cords from sharp objects, excessive heat and damp or wet areas. Keep the cord away from oil, cutting edges and moving parts.
- 9. Do not drive, drag or place objects over cord.
- 10. Avoid overheating. Uncoil cord and do not cover it with any material.
- 11. Avoid accidental starting. Be sure equipment is turned off before plugging in. Do not use equipment if the power switch does not turn the equipment on and off.

- Make sure equipment is not running before disconnecting cord.
- 13. Unplug equipment. When not in use and before changing accessories or performing maintenance, unplug the machine.

### **OPERATING THE MACHINE**

- 1. The machine is equipped with an emergency stop switch (E-stop) and a lanyard kill switch. If either switch is activated, the machine will shut down and be inoperative.
- 2. Never remove or modify any of the safety features on the machine.
  - Carefully read the manual to understand the proper use of the safety features.
  - Make sure all safety features, including the emergency stop switch, lanyard kill switch and protective guards are in good operating condition. Repair or replace any inoperative or missing safety features.
- 3. Maintain control and stay alert. Keep proper footing and balance and maintain a firm grip.
- Vibration—Device exceeds 2.5 m/s<sup>2</sup> exposure level. Consult local hand-arm vibration (HAV) guidelines for recommended exposure limits.



- 5. Always stay clear of moving parts. Clothing, hands or other body parts can become caught in moving parts of the machine and cause personal injury.
- 6. Beware of hot surfaces such as blades and motor components. Always wear safety gloves.



- 7. Blades are sharp, use extreme caution.
  - Always wear safety gloves when handling blades.
  - Never change blade holder or service the blade while machine is running.



- 8. Beware of pinch point locations.
  - Handle:
    - Gap below handle hinge
    - Between handle and machine with handle adjusted all the way forward
    - Between handle and transport wheels with handle adjusted all the way back
    - Between handle and machine while installing handle
  - Between weights and machine when removing and installing weights
  - Rear access cover while closing (both sides)
  - Tooling holder at blade holder insertion location
  - Between machine and floor while laying machine on its side



9. Use care when handling the weights. Weights are very heavy and create a crushing hazard.



- 10. Always check the surrounding area for any possible conditions that could create a dangerous situation.
  - Operator should be aware of who is around them and their proximity. Never allow people to approach the vicinity of the machine while the machine is running.
  - Bystanders should stay a minimum of 3 ft away from the machine during operation.
  - Keep children away from the machine and work area at all times.
  - Be aware of blind spots to the rear and always check behind you before backing up.
  - Provide barriers or shields as needed to protect others in the work area from flying debris and machine operation.
- 11. Electrical cords create a tripping hazard. Be careful not to trip over the extension cord while operating the machine.
- 12.Never allow people to ride on the machine.
- 13.Never step on the debris deflector during operation, as loss of balance and personal injury could occur.
- 14. Avoid leaning forward over the handle during operation. If machine is operated in reverse, drive wheel could roll over operator's foot causing possible injury.
- 15.Never lean on the handle. Putting weight onto machine could damage the handle and cause operator to lose balance.
- 16. Avoid driving the machine over any obstacles which could cause a loss of control.
- 17.Use caution when operating the machine on inclines or uneven surfaces.
  - The weight of the machine may become distributed differently if on an uneven surface. Too much of an angle could cause the machine to roll unexpectedly or roll over.
  - Max. working grade (scraping applications): 5%
  - Max. transportation grade (ramp use): 36%
- 18. Do not use on largely uneven surfaces.
- 19.Use caution when operating on slippery surfaces.
- 20. Avoid use in dangerous environments. Do not use in the presence of explosive atmospheres (gaseous fumes, dust or flammable materials). Remove materials or debris that may be ignited by sparks.

- 21.Machine is only to be used indoors. Do not use in wet environments.
  - Do not operate near standing water.
  - Do not use to scrape waterlogged carpet.
- 22. Do not block the machine's air flow. Blocking ventilation slots or air flow could result in damage to the machine. Leave space for air to flow freely during operation.
- 23.If abnormal noise or vibration occurs, turn off the machine immediately.
- 24.Do not force equipment. Equipment will perform best at the rate for which it was designed. Excessive force only causes operator fatigue, increased wear and reduced control.

- 1. Dress properly and wear adequate safety equipment when transporting the machine. All personnel in the proximity of the machine must wear eye protection, ear protection, safety shoes, safety gloves, hard hat, high visibility safety vest and dust mask. Do not wear loose clothing as it could get caught in moving parts and cause injury.
- 2. The machine is very heavy! Machine weight is shown in "MACHINE SPECIFICATIONS" section and on serial number label.
- 3. Never attempt to manually lift the machine. Hands could slip off causing serious injury.
- 4. Never lift machine by the handle, weights, blade holder or tooling holder. Weights and handle could detach causing injury. The machine could be damaged.
- 5. Use only proper lifting points and tie-down locations.
- See "TRANSPORTING THE MACHINE" section for detailed safety instructions.

### MAINTENANCE

- 1. Dress properly and wear adequate safety equipment. All personnel in the work area must wear eye protection, ear protection, safety shoes, safety gloves, hard hat, high visibility safety vest and dust mask. Do not wear loose clothing as it could get caught in moving parts and cause injury.
- 2. Maintenance should only be performed by qualified personnel.
- Always turn off machine, disconnect from power and discharge stored energy before performing maintenance. Variable frequency drives (VFDs) hold stored energy and pose a serious electrical shock hazard. Always perform the following procedure before beginning any work on machine:
  - A. Turn off machine.
  - B. Leave power cord plugged in 5 minutes.
  - C. Disconnect power cord.
  - D. Wait an additional 5 minutes before performing any service on the machine.



- 4. Allow the machine to cool down sufficiently before performing maintenance.
  - Blade and motor may be very hot immediately after the machine has been running. Allow these parts to cool sufficiently before touching.



- 5. Always stay clear of moving or rotating parts. Clothing, hands or other body parts can become caught in moving parts of the machine and cause personal injury.
- 6. Always attach a "DO NOT OPERATE" tag whenever performing any kind of maintenance or repair.
- 7. Make sure you have the proper tools on hand. Do not use defective or damaged tools. Always use tools that are appropriate for the task to be done.

- 8. Make sure the work area is clear and safe. Be sure to work on a firm, level surface with adequate lighting. Work in a well-ventilated area if indoors. Make sure the area is free from any potentially dangerous conditions such as obstacles, slippery surfaces, etc.
- 9. Prohibit unauthorized persons from entering work area.
- 10.Make sure the machine is secured before beginning maintenance work.
  - Chock the wheels to prevent the machine from rolling.
- 11. Be sure the machine is clean and free of debris before performing any maintenance work.
- 12. Motors run at high temperatures under normal conditions. Clean debris from motors more frequently when working in severe conditions.
- 13.Never use a pressure washer or hose to clean the machine. Water can seep into the electrical components causing an electrical shock hazard or malfunction of controls.
- 14.Use caution when tilting back the machine to change the blade holder:
  - Before tilting back, position slide weights rearward to make tilting easier.
  - Always block the front of the machine to prevent the machine from falling forward unexpectedly.



- 15. The machine has components that are at high temperatures under normal operating conditions. The primary source of high temperatures are the motors. The electrical system, if damaged or incorrectly maintained, can be a source of arcing or sparks. The following guidelines will help keep the machine running efficiently and keep the risk of fire to a minimum.
  - Clean accumulated flammable debris from hot components. Clean more frequently when working in severe conditions.
  - Remove rags, tools, supplies, etc. from the machine after maintenance is completed.
  - Check electrical wiring and connectors frequently for damage. Repair any wires that are loose or frayed before operating the machine. Clean and tighten all electrical connections as necessary.

- 16.Do not permanently remove a guard or other safety device when performing maintenance on the machine.
- 17. Check for loose or damaged parts, misalignment, improper mounting, binding of moving parts, and any other conditions that may affect operation.
  - Retighten all loose parts. Replace damaged parts immediately. Use only NFE parts.
  - Do not use damaged equipment until repaired.
  - Use only NFE-approved or recommended parts and accessories. Using any that are not recommended may be hazardous and will void factory warranty.
- 18.Do not modify the machine without written authorization from NFE.

- 19. Always carefully check the machine after performing any maintenance or repairs. Remove all traces of cleaning fluids from the machine.
- 20.Use proper cleaning agents. Ensure that all cleaning rags are fiber-free. Do not use any aggressive cleaning products.
- 21.Waste material
  - Consult local regulations and codes when disposing of potentially harmful and hazardous materials or substances. Dispose of waste material properly to avoid pollution and contamination of the environment.

## SAFETY

### SAFETY LABELS

406603



Eye Protection, Ear Protection, Hard Hat, Safety Shoes, Safety Gloves, Dust Mask, High Visibility Safety Vest, Read Manual

406581



Airborne Contaminants

407151



Team Lift

406110



Team Lift, Do Not Stand

#### 407124



Hot Blade, Pinch Point, Sharp Blade

407125





Pinch Point



Electrical Hazard

## THIS PAGE INTENTIONALLY LEFT BLANK



## **OPERATING CONTROLS**



#### [1] Emergency Stop Switch (E-Stop)

Push to immediately shut down the machine in case of emergency.

#### Reset Procedure

If engaged, must be reset before the machine can be restarted. To reset, twist red button clockwise to release.

#### [2] Lanyard Kill Switch

Operator presence control (OPC) that immediately shuts down the machine if the operator gets separated from the machine's controls. The switch is held open by a key attached to a lanyard that is tethered to the operator. If the operator moves too far from the switch, the lanyard pulls the key from the switch shutting down the machine.

#### Reset Procedure

If engaged, must be reset before the machine can be restarted. To reset, reinsert the key into the kill switch.

#### [3] Power Indicator

The power indicator illuminates when the machine is connected to power.

#### [4] ON Button

Push the green "ON" button to turn on the controls. The system indicator will pulsate green.

### [5] OFF Button

Push the red "OFF" button to disable the controls.

#### [6] System Indicator

Indicates system status:

- Amber indicates startup mode.
- Pulsating green indicates machine is ready to operate.
- Flashing red indicates a system fault. Reference "TROU-BLESHOOTING" section for fault codes.

#### [7] Drive Speed Control

Sets the maximum drive speed of the machine.

### [8] Orbital Motor Speed Control

Adjusts the oscillation rate of the tooling holder.

#### [9] Blade Angle Control

Adjusts the angle of the blade.

#### [10] Hour Meter

Displays operating hours.

#### [11] Left/Right-Hand Preference Switch

Determines functionality of the control handles based on operator preference.

### [12] [13] Left and Right Control Handles

The control handles are used to control the travel direction, turning and drive speed of the machine. Reference the "MA-CHINE OPERATION" section for detailed information.

### INSTALLING THE POWER CORD

- 1. Remove the two cable clamps on handle.
- 2. Route power cord (packaged with machine) through clamps.
- 3. Reinstall clamps. Use of threadlocker on bolt threads is recommended.

#### NOTE:

• Make sure there is no excess slack in the power cord.



Installed power cord



Power cord should NOT have excess slack.

### INSTALLING THE BLADE HOLDER

See "CHANGING THE BLADE HOLDER" section for installation process.



### 

To avoid personal injury:

- Always turn off machine, disconnect from power and discharge stored energy before performing maintenance. Variable frequency drives (VFDs) hold stored energy and pose a serious electrical shock hazard. Always perform the following procedure before beginning any work on machine:
  - 1. Turn off machine.
  - 2. Leave power cord plugged in 5 minutes.
  - 3. Disconnect power cord.
  - 4. Wait an additional 5 minutes before beginning any work.

### ADJUSTING THE HANDLE

### 

To avoid personal injury, be careful not to pinch hands in the following locations:

- Gap below handle hinge
- Between handle and hood with handle adjusted all the way forward.
- Between handle and transport wheels with handle adjusted all the way back.

While pulling the handle release lever, slowly move the handle to the desired position. Handle will "click" into place.



Adjusting handle.

### ADJUSTING THE WHEEL SCRAPERS

- 1. Loosen the nuts.
- 2. Adjust wheel scrapers so there is a gap of .13-.18" (3-5 mm) between the scraper and wheel.
- 3. Retighten nuts.

#### NOTE:

• Scraper should not contact the wheel, as damage to wheel could occur.



Wheel cleaner adjusted to proper gap.



Wheel cleaner should NOT contact wheel.

## **MACHINE OPERATION**

### WEIGHTS

### 

To avoid personal injury:

- Weights are very heavy and create a crushing hazard. Use care when handling the weights.
- Beware of pinch point locations between weights and machine while installing weights.
- Make sure to properly secure the weights after installing. Unsecured weights could fall off causing injury.

#### NOTE:

- The front weight must be installed for all scraping applications to ensure proper machine operation. Do not perform scraping without the front weight.
- Middle and slide weights should remain installed for the majority of applications.
- Use the 6 mm extended "T" wrench (supplied) to loosen the locking screws.



(A) Front weight

- (B) Middle weights
- (C) Slide weights

#### Removing Front Weight

### 

To avoid personal injury:

- The person lifting front weight should have the ability to lift 70 lbs. Otherwise a team lift of two people is highly recommended.
- When removing the front weight, make sure weight doesn't bind with the locating posts causing machine to be lifted along with the weight. Machine could detach from the weight causing serious injury.
- 1 weight, 66 lbs (29.9 kg)
- 1. Loosen locking screws a few turns but do not remove.
- 2. Carefully remove weight as shown.



Loosening front weight locking screws. (Right side not shown.)



Removing front weight.

#### Removing Middle Weights

- 2 weights (1 weight per side), 28 lbs (12.7 kg) each
- 1. Loosen locking screws a few turns but do not remove. The rearward screw is accessed through the opening in the hood.
- 2. Carefully remove weight.



Loosening middle weight locking screws.



Removing middle weight.

#### Removing/Adjusting Slide Weights

### 

To avoid personal injury:

- When adjusting or removing the slide weights, be sure to hold the weight with one hand while loosening the screws. Otherwise, weight will slide causing possible injury.
- 2 weights (1 weight per side), 28 lbs (12.7 kg) each

#### NOTE:

- The slide weights are adjustable:
  - Position forward for more blade pressure.
  - Position rearward to provide better traction for the drive wheels.
  - Always position rearward before tilting machine back.

#### Adjusting Slide Weights

- 1. Loosen locking screws about one turn but do not remove.
- 2. Slide weight along rail to desired position. Make sure weight is not resting against hood.
- 3. Retighten screws.

#### Removing Slide Weights

- 1. Loosen locking screws about one turn but do not remove.
- 2. Carefully slide weight from top of rail.



Adjusting slide weight.

## **MACHINE OPERATION**

### WHEEL MODES

The wheels engage and disengage for better maneuverability.

- When the wheels are disengaged (freewheel mode), the coupling flanges disengage the wheels from the axle so the machine can be freewheeled when not under power.
- When the wheels are engaged (drive mode), the coupling flanges engage the wheels with the axle so the machine can be driven under power.

### Disengaging Wheels

### 

To avoid personal injury:

• Always make sure machine is on level ground before disengaging wheels.

Pull out each coupling flange and rotate 45° so it does not retract.

#### NOTE:

• If the coupling flange is difficult to pull out, turn the wheel slightly to reduce the friction and try again.



Wheel disengaged. Coupling flange is pulled out.

#### Engaging Wheels

- 1. Rotate each coupling flange until it "clicks" into place.
- 2. Move the machine slowly forward to rotate the wheels until both wheels fully engage.



Wheel fully engaged. Coupling flange is fully retracted.

### JOBSITE EXPECTATIONS

- Make sure the jobsite is equipped with the proper power source for the machine requirements.
- Keep work area well-lit.
- Keep work area clean and clear of debris. After removing a portion of material, move it out of the way.
- Pound down or remove any nails or metal obstruction on wood or wood-like floors to avoid blade damage.

### PREPARING FOR OPERATION

Complete the following before starting the machine:

- 1. Inspect wheels, tooling holder, blade holder, handle harness and power cord for damage. Check for loose or missing fasteners.
- 2. Clean built-up glue and debris from wheels, front weight and blade holder.

### STARTING THE MACHINE

## 

To avoid personal injury:

- Avoid excessive pushing, pulling and twisting of control handles, as machine could be damaged.
- 1. Install desired tooling.
- 2. Make sure the wheels are engaged.
- 3. Make sure the orbital motor speed is set "below 1".
- 4. Plug machine into power source. Verify the power indicator illuminates.
- 5. Verify the E-stop and lanyard kill switch are not engaged.
- 6. Tether lanyard kill switch to wrist.
- 7. Push the "ON" button to turn on the machine. The system indicator will turn amber during startup mode (approximately 10 seconds), then pulsate green indicating machine is ready to operate.
- 8. Adjust the maximum drive speed.
- 9. Adjust orbital motor speed to the desired oscillation rate.

#### NOTE:

- NFE recommends adjusting the orbital motor speed only as high as necessary to perform the job. Lower speeds reduce hand-arm vibration and noise levels.
- 10.Adjust blade angle to the angle at which the material comes up the easiest.
- 11. Set left/right-hand preference switch for desired functionality of the control handles.
- 12.Use the control handles to control the travel direction, speed and turning of the machine.

### **STOPPING THE MACHINE**

- 1. Turn the orbital motor speed control fully counterclockwise to the "below 1" position.
- 2. Push the "OFF" button.

### AFTER OPERATION

- 1. Disconnect machine from power.
- 2. Clean built-up glue and debris from wheels, front weight and blade holder.
- 3. IMPORTANT:
  - Relubricate the wheel bearings after daily use by disengaging the wheels, then pushing the machine ahead in freewheel mode allowing the wheels to rotate at least three turns.
- 4. Engage the wheels so the machine is in drive mode.
- 5. Remove tooling.
- 6. Store machine in a dry, secure place.

### **DRIVING THE MACHINE**

- The left/right-hand preference switch determines the functionality of the control handles.
- The control handles are proportional controls, meaning the more you rotate the control, the faster the machine moves.

#### Left-Hand Preference

- Left Control Handle = Forward/Reverse
- Right Control Handle = Turn





### DRIVING THE MACHINE (CONT'D)

#### ■ Right-Hand Preference

- Right Control Handle = Forward/Reverse
- Left Control Handle = Turn





## **MACHINE OPERATION**

### CHANGING THE BLADE HOLDER

### 

To avoid personal injury:

- Before tilting machine back, position the slide weights rearward to make tilting easier.
- Always block the front of the machine to prevent the machine from falling forward unexpectedly.
- Always wear safety gloves when handling blade holders. Blade holders get very hot while scraping. Blades are sharp.
- 1. Position the slide weights rearward.
- 2. Slowly tilt the machine back using the kickplate.
- 3. Block up machine. Place block under linkage.
- 4. While pushing button, remove blade holder from the tooling holder.
- 5. Insert the new blade holder into the tooling holder. Make sure the blade holder is fully engaged and secure.

#### NOTE:

- The blade holder should swivel freely in the tooling holder. This allows the blade to stay in contact with the floor. White lithium grease may need to be applied to the shaft of the blade holder before inserting.
- The swivel-lock feature allows the blade holder to be locked into place for certain applications. To prevent the blade holder from swiveling, tighten the screw on the side of the tooling holder using the 6 mm extended "T" wrench (supplied).



Installing the blade holder.



Swivel-lock feature

## **MACHINE OPERATION**

### CHANGING THE BLADE

### 

To avoid personal injury:

- Always wear safety gloves when handling blades. Blades are sharp and could be very hot.
- Remove blade holder from tooling holder and place on level surface before replacing blade.
- 1. Remove blade holder from machine.
- Loosen the hex head cap screws keeping hand safely away from sharp edge of the blade. It is not necessary to remove the screws.
- 3. Remove old blade.
- 4. Place new blade into the blade holder and slide back until fully seated against the notch.

#### **IMPORTANT:**

• Do not insert blade all the way back to the screws. Incorrect installation will cause insufficient clamping leading to premature blade wear and damage.

If the blade is wider than the blade holder, center the blade in the holder. If the blade is smaller than the blade holder, the blade should be mounted in the center of the holder during the first pass. After the first pass is made, the blade can be offset in the holder to allow the wheels to keep even contact with the floor and provide easy access to the wall.

- 5. Tighten the screws.
- 6. Reinstall blade holder.



Removing the blade.



Blade fully seated against notch.



Offset blade

### BLADES

#### Blade Setup

- Dull blades greatly affect the performance of the machine and reduce cutting ability. Sharpen or replace as needed.
- Depending on the material and sub-floor type, proper blade size and placement will affect performance.
- For harder jobs, use a smaller blade.
- Start with a narrow blade, then increase blade size to optimize cutting pass. Narrower blades work easier than wider blades, and usually clean the floor better. Wider is not always better or faster.
- Normally the bevel on the blade is down for wood, bevel up for concrete.



Standard blade in blade holder, bevel down for wood.



Standard blade in blade holder, bevel up for concrete.

• Blades can be offset in the blade holder for easier access to toe kicks or for removal along the wall.

#### Self-Scoring Blades

- Self-scoring blades eliminate the need for pre-scoring material and are designed for monolithic flooring, laminate, carpet and sheet materials. Depending upon the type of material being removed and the sharpness of the blade and scoring wings, the self-scoring blades may make it harder to control the machine. Keep scoring wings sharp at all times.
- Sheet vinyl, solid vinyl, rubber tile and urethane need to be scored for best results. NFE recommends using a self-scoring blade.



Bevel down self-scoring 90° blade



Bevel up self-scoring 90° blade

### APPLICATIONS

The machine is designed for hard and soft goods removal applications:

### VCT Tile

Never use a blade wider than the size of the tile being removed. If material still does not come up clean or machine jumps on top of material, reduce blade size or use a smaller portion of the blade.

### Pure Vinyl Rubber Tile

A 10" (25.4 cm) self-scoring blade is recommended for this application.

### Ceramic

Carbide shanks are most effective for removing ceramic. On small block-styles of tile, pre-breaking may not be necessary. Open an area large enough for machine or blade to fit in, or start from a doorway. Use slow speed.

#### Direct-Glued Carpet

NFE recommends using a self-scoring blade. Normally 6-14" (15.2-35.6 cm) self-scoring blades are used on directglued carpet, secondary-backed, unitary, double-glued, vinyl foam and urethane foam.

### Wood

Wood floor shank (#7082-8GV) will usually work best. In most instances it is necessary to pre-score the wood floor every 6-8" (15.2-20.3 cm), 90% through the floor, in a cross-grain fashion. Adjust blade angle to keep the shank low to the floor. Using the machine on a slow speed will help.

### Thin Coatings

Use 1" (2.5 cm) blades with a razor blade blade holder or a carbide shank. Experiment to see which method works the best for the job application.

### ■ Re-Scrape

Use razor blades with a razor blade blade holder or a .062" standard blade. Turn off oscillation. Use a steeper angle of attack if necessary. Experiment to see which method works the best for the job application.

#### Subfloor Surfaces

#### Glued Hardwood Flooring

A 10" (25.4 cm) blade is recommended for regular adhesive; a 6" (15.2 cm) blade for epoxy. For proper removal of hardwood flooring (plank solid, plank laminated, parkay laminated), flooring must be scored to blade width. NFE recommends using an NFE scarifier equipped with a woodscoring scarifier drum. Set scarifier at a depth of 99% of the thickness of the board, just missing the subfloor surface when on concrete. For true parkay flooring, scoring is not necessary. It will come up in small pieces. Open an area large enough to fit machine or start from a doorway.

#### ♦ Wood

When working over plywood sub-flooring, run machine in the same direction as the grain in the wood. Blade works best bevel down. On solid wood floors (e.g., plank), run in the same direction as the plank, not perpendicular to grain or plank. Removing the front weight will help on all soft surfaces.

#### Concrete

For best performance, position blade bevel up when working on a concrete slab or cleaning adhesive. On occasion, bevel down gives better blade life. Test each job for best performance.

#### Gypcrete and Soft-Poured Flooring

Position blade bevel down to create a better wearing surface, although bevel up may work if front weight is removed.

### TRANSPORT WHEELS

Transport wheels are used to move the machine around the jobsite or for loading the machine onto a vehicle. They allow for easier movement and provide stability.

### 

To avoid personal injury:

- Before tilting machine back, position the slide weights rearward to make tilting easier.
- Always block the front of the machine to prevent the machine from falling forward unexpectedly.
- 1. Position the slide weights rearward.
- 2. Slowly tilt the machine back using the kickplate.
- 3. Block up machine. Place block under linkage.
- 4. Insert the transport wheels into the tooling holder. Make sure the transport wheels are fully engaged and secure.
- 5. For better maneuverability, adjust the blade angle so the transport wheels bracket is parallel to the floor.

#### NOTE:

• When not in use, store transport wheels on the handle orientated as shown.



Installing transport wheels.



Good maneuverability--bracket parallel to floor.



Poor maneuverability--bracket NOT parallel to floor.



Proper orientation for transport wheels in stowed position

### VEHICLE WITH POWER LIFTGATE

Using a truck or van equipped with a power liftgate is the recommended way of transporting the machine by vehicle.

### 

To avoid personal injury:

• Instructions for safe transporting using a vehicle equipped with a power liftgate are described below. Read these instructions carefully before transporting. Personnel in proximity of the machine must wear adequate safety equipment.

#### **IMPORTANT:**

- Make sure the load capacity of the liftgate is greater than the weight of the operator and machine.
- Machine weight is shown in "MACHINE SPECIFICA-TIONS" section and on serial number label.
- Make sure weights are properly secured to the machine.
- Use the transport wheels when loading and unloading.
- Engage wheels and use wheel chocks to stabilize machine on liftgate.
- Before tying down machine, engage wheels and install empty blade holder for stability.
- Use appropriate tie-down hardware to secure machine.
- Always inspect the tie-down hardware before each use. Do not use if worn or damaged.
- Use only proper tie-down locations. Do not attach the tie-down hardware to handle, weights, blade holder or tooling holder. Weights and handle could detach causing injury. The machine could be damaged.
- Load disengagement can cause severe injury or property damage. Always make sure tie-down hardware is properly connected.
- Make sure all attachments are properly secured during transport.
- Follow your company's safety guidelines to avoid injury.
- 1. Make sure transport wheels are installed.
- 2. Move machine onto liftgate.
- 3. Engage wheels and chock wheels to stabilize machine on liftgate.
- 4. Move machine into truck.
- 5. Before tying down machine, engage wheels and install empty blade holder for stability.
- 6. Tie down the machine using proper tie-down locations.



Transporting with power liftgate



Tie-down locations

### VEHICLE WITH RAMP

If a liftgate is not available, a ramp may be used to load and unload the machine.

### 

To avoid personal injury:

• Instructions for safe transporting using a vehicle equipped with a ramp are described below. Read these instructions carefully before transporting. Personnel in proximity of the machine must wear adequate safety equipment.

#### IMPORTANT:

- Make sure the load capacity of the ramp is greater than the weight of the operator and machine.
- Machine weight is shown in "MACHINE SPECIFICA-TIONS" section and on serial number label.
- Make sure the ramp is not damaged and properly secured to the truck/trailer bed.
- Do not use the machine on a ramp that exceeds a 36% grade (20° incline).
- Remove all weights from machine before loading and unloading. Make sure weights are properly secured during transport.
- Use the transport wheels when loading and unloading.
- Drive the machine under power when moving the machine up or down the ramp. Using the freewheel mode could result in loss of control causing serious injury.
- Operator should never be positioned below machine on the ramp. Always back the machine up the ramp and drive the machine down the ramp.
- Drive the machine slowly. Do not make directional changes when machine is on the ramp.
- Electrical cords create a tripping hazard. Be careful not to trip over the extension cord while driving the machine.
- Before tying down machine, make sure wheels are engaged and install empty blade holder for stability.
- Use appropriate tie-down hardware to secure machine.
- Always inspect the tie-down hardware before each use. Do not use if worn or damaged.
- Use only proper tie-down locations. Do not attach the tie-down hardware to handle, weights, cutting head or tooling holder. Weights and handle could detach causing injury. The machine could be damaged.
- Load disengagement can cause severe injury or property damage. Always make sure tie-down hardware is properly connected.
- Make sure all attachments are properly secured during transport.
- Follow your company's safety guidelines to avoid injury.



Tie-down locations

#### Ramp Loading

- 1. Remove weights.
- 2. Make sure transport wheels are installed.
- 3. Engage the wheels so the machine is in drive mode.
- 4. Plug machine into power source.
- 5. Turn on the machine and slowly back up the ramp.
- 6. Turn off machine and unplug from power source.
- 7. Remove transport wheels and install empty blade holder for stability.
- 8. Tie down the machine using proper tie-down locations.

#### Ramp Unloading

- 1. Make sure weights are removed.
- 2. Remove blade holder and install transport wheels.
- 3. Make sure the wheels are engaged so the machine is in drive mode.
- 4. Plug machine into power source.
- 5. Turn on the machine and slowly drive down the ramp. **NOTE:** 
  - Use caution when driving down ramp as the machine will overrun the drive motor speed. Pulsate the control handle knob in reverse to "brake" the machine.
- 6. Turn off machine and unplug from power source.
- 7. Attach weights making sure to properly secure to machine.

### HOISTING

### 

To avoid personal injury:

• Instructions for safe hoisting are described below. Read these instructions carefully before hoisting. Personnel in proximity of the machine must wear adequate safety equipment.

#### **IMPORTANT:**

- Choose lifting hardware appropriate for the weight and configuration of the machine.
- Machine weight is shown in "MACHINE SPECIFICA-TIONS" section and on serial number label.
- Do not lift loads that exceed the maximum rated capacity of the hoist and the lifting hardware.
- Be sure the hooks have a safety latch.
- Always inspect the lifting hardware before each use. Do not use if worn or damaged.
- Be sure the weights and blade holder are properly secured to the machine before hoisting.
- Use only proper lifting points. Do not attach lifting hardware to handle, weights, blade holder or tooling holder. Weights and handle could detach causing injury. The machine could be damaged.
- Do not enter and do not allow others to enter the working area under the suspended load. Do not move the load over people.
- Load disengagement can cause severe injury. Always make sure lifting hardware is properly connected.
- Follow your company's safety guidelines to avoid injury.
- 1. Shut off machine and unplug from power source.
- 2. Bundle the cord and tuck in front of the handle to prevent cord from dragging on the floor.
- 3. Attach lifting hardware to the proper lifting points.
- 4. Using hoist, lift the machine slowly.



Lifting points

### 

National Flooring Equipment, Inc will not be held liable or responsible for any misuse of transport poles, including but not limited to installation, alteration, or use outside of their intended purpose or design. Customers agree to hold National harmless from any claims, damages, or liabilities arising from such misuse. For the safety and optimal performance of our products, we strongly recommend adhering to all usage guidelines and instructions provided by our company.

### **Transport Poles (Optional)**

If job site has stairs, then lifting poles may be utilized.

### 

To avoid personal injury:

• Instructions for safely transporting using the lifting poles are described below. Read these instructions carefully before transporting. Personnel in proximity of the machine must wear adequate safety equipment.

#### **IMPORTANT:**

- Remove all weights and handle before lifting.
- Do Not lift more than instructed. Lifting poles are rated for lifting the unloaded machine without the weights and handle.
- Unloaded machine weighs 262 lbs (118.4 kg); a 4 person lift is suggested.
- Make sure the transportation area is clear of debris and tripping hazards.
- Always inspect the lifting poles, connection points and hardware before each use. Do not use if worn or damaged.
- Use only proper lifting pole locations and hardware.
- Load disengagement can cause severe injury or property damage. Always make sure lifting poles are properly connected and all removable weight has been removed.
- Make sure all poles are properly secured before transport.
- Follow your company's safety guidelines to avoid injury.

- 1. Disconnect machine from power.
- 2. Remove all slide weights; 28 lbs (12.7 kg) each.
- 3. Remove front weight; 68.3 lbs (30.98 kg).
- 4. Remove middle weights; 28 lbs (12.7 kg) each.
- 5. Remove tooling or transport wheels from tooling holder.
- 6. Remove handle from machine; 33 lbs (15 kg). Power cord and handle harness must be disconnected at the base of the handle before removal. (Fig. 1)
- 7. Verify all body panel screws are present and tightened securely. (Fig. 2)
- 8. Fit lifting poles over rear ends of the slide weight rods and lock into place with locking pins. (Fig. 3 5)
- 9. Lean machine back, fit lifting poles over front ends of the slide weight rods and lock into place with locking pins.
- 10. Machine can now be lifted by 4 people.



Fig. 1 - Machine with all weights and handle removed.



Fig. 2 - Body panel screws. Not shown, two on opposite face and two on rear face.
# TRANSPORTING THE MACHINE





Fig 3 - Transport pole lock holes.

Scan QR Code for video instruction.



Fig. 4 - Machine with transport poles installed.



Fig 5 - Locked position of pin.

## 

To avoid personal injury:

- Always turn off machine, disconnect from power and discharge stored energy before performing maintenance. Variable frequency drives (VFDs) hold stored energy and pose a serious electrical shock hazard. Always perform the following procedure before beginning any work on the machine:
  - 1. Turn off machine.
  - 2. Leave power cord plugged in 5 minutes.
  - 3. Disconnect power cord.
  - 4. Wait an additional 5 minutes before beginning any work.

To ensure the machine operates safely for a long time, perform regular maintenance according to the following schedule.

#### **MAINTENANCE SCHEDULE**

|   | SERVICE INTERVAL |         |                  |                   |
|---|------------------|---------|------------------|-------------------|
| MAINTENANCE TO BE PERFORMED   | Daily            | Monthly | Every<br>500 hrs | Every<br>1000 hrs |
| Inspect wheels, tooling holder, blade holder, handle harness and power cord for damage. Check for loose or missing fasteners. | •                |         |                  |                   |
| Clean built-up glue and debris from wheels, wheel cleaners, front weight, deflector and blade holder.                         | •                |         |                  |                   |
| Test E-stop and lanyard kill switch for proper functioning.   |                  | •       |                  |                   |
| Test GFCI for proper functioning.   |                  | •       |                  |                   |
| Inspect linear actuator foam pads and wear liners for excessive wear.<br>Replace as needed.                                   |                  |         | •                |                   |
| Remove wheel coupling flanges and clean any built-up debris.  |                  |         |                  | •                 |
| Inspect isolators. Replace as needed.   |                  |         |                  | •                 |
| Inspect and grease cutting head bearing. Replace as needed.   |                  |         |                  | •                 |
| Inspect blade angle linkage for excessive play. Grease linkage.   |                  |         |                  | •                 |

#### **REASSEMBLING COMPONENTS**

Use of threadlocker on fasteners is recommended when reassembling components after performing maintenance.

### **REMOVING THE HOOD**

- 1. Remove the slide weights.
- 2. Remove the top screws.
- 3. Remove the rear screws.
- 4. Loosen the side screws but do not remove.
- 5. Remove the hood.



Hood screw locations (left side not shown)



Removing hood.

#### **INSPECTING FOR DAMAGE**

#### SERVICE INTERVAL:

Daily

Inspect wheels, tooling holder, blade holder, handle harness, power cord for damage. Check for loose or missing fasteners.

#### **CLEANING DEBRIS BUILDUP**

## 

To avoid personal injury:

• Never use a pressure washer or hose to clean the machine. Water can seep into the electrical components causing an electrical shock hazard or malfunction of controls.

#### SERVICE INTERVAL:

• Daily

Clean built-up glue and debris from wheels, wheel cleaners, front weight, deflector and blade holder.

#### **TESTING THE SAFETY CIRCUIT**

#### SERVICE INTERVAL:

• Monthly

#### Emergency Stop Switch

- 1. Start machine.
- 2. Push the emergency stop switch and verify machine shuts down.
- 3. Reset emergency stop switch.

#### Lanyard Kill Switch

- 1. Start machine.
- 2. Pull the lanyard from the kill switch and verify the machine shuts down.
- 3. Reset the lanyard kill switch.

# MAINTENANCE

## **TESTING THE GROUND FAULT CIRCUIT**

# 

To avoid personal injury:

- Be sure to follow all electrical safety instructions described in "SAFETY" section.
- The ground fault circuit interrupter (GFCI) must be tested with the machine plugged into a power source and turned off.

#### SERVICE INTERVAL:

- Monthly
- 1. Remove the hood.
- 2. Pry up the plug using a flat head screwdriver.
- 3. Push "TEST" button. The GFCI should trip.
- 4. Reset GFCI by flipping switch upward to "ON" position.



Ground fault circuit interrupter (GFCI)



GFCI access port with plug installed



GFCI access port with plug removed (some components not shown for clarity)

## **INSPECTING THE PADS AND LINERS**

#### SERVICE INTERVAL:

- Every 500 hours
- 1. Remove the front weight to access the linear actuator assembly.
- 2. Inspect foam pads (1) and wear liners (2) for excessive wear. Replace as needed.



Foam pads and wear liners (weights not shown for clarity)



Foam pads and wear liners (weights not shown for clarity)

## **CLEANING THE COUPLING FLANGES**

#### SERVICE INTERVAL:

- Every 1000 hours
- 1. Remove front and slide weights.
- 2. Carefully lay the machine on its side.
- 3. Remove retaining screw (1), washer (2), spring (3) and coupling flange (4).
- 4. Clean built-up debris from the coupling flange.
- 5. Clean built-up debris from the wheel holes.



Coupling flange disassembly

#### ISOLATORS AND CUTTING HEAD BEARING

#### SERVICE INTERVAL:

- Inspect isolators and cutting head bearing every 1000 hours. Replace as needed.
- Grease cutting head bearing during inspection.

#### Inspection

- 1. Remove front and slide weights.
- 2. Remove the bottom cover.
- 3. Carefully lay the machine on its side so the isolators (1) and cutting head bearing (5) are accessible.
- 4. Inspect the isolators and cutting head bearing for damage, wear and excessive play.
- 5. Grease the cutting head bearing using Chevron SRI Grease 2 or equivalent.
- If isolators and cutting head bearing are in good condition, reverse Steps 1-3. If replacement is needed, continue to Step 7.

#### Removal and Replacement

- 7. Carefully lift machine to its upright position.
- 8. Remove middle weights.
- 9. Remove hood.
- 10. Carefully lay the machine on its side so the isolators and cutting head bearing are accessible.
- 11. For each isolator (1), hold the nut (2) on top side of frame and remove the hex head screw (4) and washer (3).
- 12. Snip cable ties and disconnect plug (9).
- 13. Using a swiveling and rocking motion, pull the full subassembly away from the eccentric (8).
- 14. If not replacing the cutting head bearing skip to Step 19.

#### Removing/Replacing the Cutting Head Bearing

- 15.Hold nuts (6) on top side of frame and remove the cap screws (7).
- 16. Remove worn bearing (5).
- 17. Visually center the new bearing with the plate opening.
- 18.Install new bearing and secure using nuts (6) and cap screws (7).

#### Removing/Replacing the Isolators

19. Remove worn isolators (1).

#### 20. Install new isolators.

#### NOTE:

- Each isolator (1) consists of 2 rubber halves and a steel tube. Both rubber halves have a boss which must be centered in the plate opening.
- 21. Move the full subassembly back into position by sliding the bearing (5) over the eccentric (8).
- 22. Secure the full subassembly using the hex head screws(4), washers (3) and nuts (2). Tighten the screws until you bottom out on the steel tubes of the isolators.
- 23. Reconnect the plug (9). Route cable as shown, securing with two cable ties.
- 24.Replace hood.



Proper cable routing

# MAINTENANCE

## ISOLATORS AND CUTTING HEAD BEARING (CONT'D)



# INSPECTING/GREASING THE BLADE ANGLE LINKAGE

#### SERVICE INTERVAL:

- Every 1000 hours
- 1. Remove front and slide weights.
- 2. Carefully lay the machine on its side.
- 3. Inspect blade angle linkage for excessive play.
  - If there is excessive play in the linkage, contact NFE technical services for assistance.
- 4. Grease the four Zerk fittings using a mineral-based, lithium-thickened grease with graphite additive (McMaster-Carr part number 10195K823 or suitable equivalent).



Blade angle linkage

#### **CLEARING JAMS**

- 1. Remove front and slide weights.
- 2. Remove the bottom cover.
- 3. Carefully lay the machine on its side.
- 4. Inspect the area around the linear actuator and blade angle linkage for any debris or obstructions.
- 5. Remove obstruction.



Actuator area



Linkage area

#### **REMOVING/REPLACING THE WHEELS**

The wheels can be removed to more easily reach obstructions.

#### Removing Wheel

- 1. Remove front and slide weights.
- 2. Carefully lay the machine on its side.
- 3. Remove retaining screw (1).
- 4. Remove washer (2), spring (3) and coupling flange (4).
- 5. Remove retaining ring (5).
- 6. Remove shim (6) and drive wheel (7).
- 7. Remove shim (6).

#### Replacing Wheel

- 8. Wipe axle (8) clean and lubricate with white lithium grease.
- 9. Repack both wheel bearings with white lithium grease.
- 10.Replace shim (6).
- 11. Replace drive wheel (7) and shim (6).
- 12. Reinstall retaining ring (5).
  - Make sure the retaining ring was not overly flexed and snaps tight into the groove.
- 13. Replace coupling flange (4), spring (3) and washer (2).
- 14. Replace retaining screw (1) and tighten.



#### **REMOVING/REINSTALLING THE HANDLE**

# 

To avoid personal injury, be careful not to pinch hands in the following locations:

• Between the handle and machine while reinstalling handle.

#### Removing Handle

- 1. Unplug power cord from base of handle.
- 2. Unplug handle harness.
- 3. Using the 6 mm extended "T" wrench (supplied), remove the 4 mounting screws at the base of handle.
- 4. Carefully lift handle from machine.



- (A) Handle mounting screws (left side not shown)
- (B) Power cord plug
- (C) Handle harness plug



Removing handle.

#### Reinstalling Handle

To reinstall the handle, reverse the previous steps. Make sure all the screws are tightened.

#### NOTE:

- When plugging in the handle harness, be sure to properly orientate the harness plug with the socket.
- Make sure there is no excess slack in the power cord.



Proper slack in power cord



Power cord should NOT have excess slack.

#### **ADJUSTING HANDLE PIVOT**

The handle pivot tension can be adjusted by turning the four set screws on the handle hinge.



Pivot tension adjustment screws

## ADJUSTING HANDLE RELEASE LEVER

- 1. Remove the small handle cover by loosening the four Torx screws.
- 2. Using a small wrench, turn the adjustment nut to remove all of the end play in the threaded rod and avoid dead travel with the release lever.

#### **IMPORTANT:**

• Only remove the end play. Do not overtighten nut as the handle hinge could unexpectedly release.



Adjusting the handle release lever.

## ADJUSTING CONTROL HANDLE KNOBS

The position of the control handle knobs may be adjusted depending on operator preference.

- 1. Remove screw.
- 2. Remove knob and reinstall to desired orientation.
- 3. Reinstall screw.



Control handle knob removed.

# MANUAL OVERRIDE OF THE LINEAR ACTUATOR

In case of unexpected loss of power, the blade angle can be adjusted by manually moving the linear actuator. This allows for power-free movement of the actuator.

- 1. Remove the front weight.
- 2. Using the 6 mm extended "T" wrench (supplied), remove the plug covering the manual override.
- 3. Use the wrench to turn the manual override clockwise or counterclockwise as needed to move the actuator.

#### **IMPORTANT:**

• Do not manually overtravel the actuator. The internal limit switches that limit travel will not function during manual adjustment.



Manually adjusting the linear actuator.

# RESETTING THE ONBOARD CIRCUIT BREAKER

If the onboard circuit breaker has been tripped, the machine will not run. Push the overload reset button to reset.



Resetting the onboard circuit breaker.

## LONG TERM STORAGE

## 

To avoid personal injury:

- Never use a pressure washer or hose to clean the machine. Water can seep into the electrical components causing an electrical shock hazard or malfunction of controls.
- 1. Disconnect machine from power.
- 2. Clean built-up glue and debris from wheels, wheel scrapers, front weight, deflector and blade holder.
- 3. Relubricate the wheel bearings by disengaging the wheels, then pushing the machine ahead in freewheel mode allowing the wheels to rotate at least three turns.
- 4. Engage the wheels so the machine is in drive mode.
- 5. Remove tooling.
- 6. Store machine in a dry, secure place.
- 7. Cover machine.

## **TROUBLESHOOTING GUIDE**

| PROBLEM  | CAUSE  | SOLUTION  |
|--|--|---|
|  | Insufficient power   | Ensure machine is plugged into a proper power source<br>with a proper extension cord. The power indicator illumi-<br>nates when the machine is plugged into a power source. |
|  | Power cord plug not fully inserted.  | Firmly press the power cord into the inlet in the base of handle.   |
|  | E-stop engaged.  | Reset E-stop by twisting clockwise, red button will pop up.   |
|  | Lanyard kill switch engaged.   | Ensure lanyard key is properly inserted into kill switch.   |
|  | Onboard circuit breaker is tripped.  | Reset the onboard circuit breaker by pushing the overload reset button. Contact NFE technical services if the breaker unexpectedly trips.                                   |
|  | Handle harness plug is disconnected.   | Ensure the handle harness plug is properly seated and locked.   |
| Machine will not start.                        | "ON" button was not pushed   | Push "ON" button to boot up machine. Allow a few seconds to boot up, the status indicator will pulsate green.   |
|  | System fault   | The status indicator flashing red indicates a system fault.<br>See "TROUBLESHOOTING" section for fault blink codes.   |
|  | "ON" button is pushed too quickly after<br>machine is shut down (e.g., "OFF" button is<br>pushed, machine is unplugged, E-stop or<br>lanyard kill switch are engaged). | The electronics need to dissipate stored energy while pow-<br>ering down. Allow 10 seconds before restarting machine.<br>Failing to do so may result in a system fault.     |
|  | System indicator is pulsating green, but nothing is happening.   | When orbital motor speed is set "below 1" the orbital motor is off. Turn dial to increase the oscillation rate.   |
|  | Handle harness plug is damaged.  | Unplug the handle harness and inspect the contact pins for damage. Replace as necessary.  |
|  | GFCI is tripped.   | Reset GFCI. See "MAINTENANCE" section.  |
| Machine will not move under power.             | Wheels are disengaged.   | Rotate coupling flanges until they "click". Move the ma-<br>chine forward slowly to engage the wheels.  |
| Machine is difficult to move<br>without power. | Wheels are engaged.  | Disengage wheels by pulling out coupling flanges and rotating 45° so they do not retract.   |
| Machine will not move.                         | Wheels are obstructed.   | Inspect wheels for debris that could be obstructing them. If obstructions are present, see "MAINTENANCE" section for wheel removal procedure. Remove obstruction.           |
|  | Wheel scrapers are contacting wheels.  | Ensure there is a slight gap between each wheel and scraper.  |
| Machina vaara ta laft ar right                 | Tracking out of adjustment.  | Contact NFE technical services for assistance.  |
| when driving straight ahead.                   | One of the wheel couplers is engaged and the other is disengaged.  | Make sure both wheel couplers are engaged.  |
| Machine is tripping external circuit breaker.  | A circuit overload is occurring.   | Look for any obstructions that could be causing excessive overloading. Contact NFE technical services to further diagnose.  |

# TROUBLESHOOTING

## TROUBLESHOOTING GUIDE (CONT'D)

| PROBLEM   | CAUSE   | SOLUTION   |
|---|---|--|
|   | Orbital motor speed is set "below 1".                                   | When orbital motor speed is set "below 1" the orbital motor is off. Turn dial to increase the oscillation rate.  |
| Blade holder is not oscillating.                              | Orbital motor speed is set "above 1" but there is still no oscillation. | If status indicator is pulsating green, shut off machine and check for any obstructions. See "MAINTENANCE" section for clearing jams procedure.                                |
| Control handles are operating in reverse.                     | Left/right-hand preference switch is set to the wrong preference.       | Change switch to reverse control handle functionality.   |
|   | Orbital motor speed is set too high.                                    | NFE recommends adjusting the orbital motor speed only<br>as high as necessary to perform the job. Lower speeds<br>reduce hand-arm vibration and reduce noise levels.           |
|   | Scraping with front weight removed.                                     | The front weight must be installed for all scraping applica-<br>tions. Replace the front weight.   |
|   | Weights vibrating.  | Secure all weights by tightening the locking screws.   |
| Machine is too loud or experi-<br>encing excessive vibration. | Slide weights chattering against hood.                                  | Loosen the locking screws, rotate weight away from hood, then retighten screws.  |
|   | Hood screws missing.  | Ensure that all hood screws are in place. Start all fasteners before tightening down.  |
|   | Handle screws not secured.  | Ensure handle mounting screws are secure.  |
|   | Operating near an undesirable frequency.                                | Certain frequencies known to cause undesirable vibration<br>have been disabled; however, it may still improve perfor-<br>mance to slightly increase or decrease orbital speed. |
|   | End of travel   | Blade angle adjustment is limited. Verify the blade will adjust in the opposite direction.   |
| Blade angle will not adjust.                                  | Internal overload protection tripped.                                   | Wait several minutes for the internal overload built into the wire harness to cool and reset (it is self-resetting). Check for obstruction causing the overload.               |
|   | Obstruction   | If a noise can be heard when adjusting the blade angle, it may be due to a blockage or binding. Contact NFE technical services to further diagnose.                            |
|   | Broken/obstructed cooling fan   | The orbital motor operates with free airflow from the fan cover. A damaged fan cover or fan blade could result in overheating. Replace/repair as needed.                       |
| Orbital motor heating up.                                     | Obstructions in orbital cutting head plate                              | See "MAINTENANCE" section for inspection procedure.<br>The eccentric can be turned back and forth to ensure free<br>movement.  |
|   | Cutting head bearing failure  | Replace bearing. See "MAINTENANCE" section.  |
|   | Isolators worn out.   | Replace isolators. See "MAINTENANCE" section.  |
| Blade holder does not swivel freely in tooling holder.        | Rotation is locked.   | Loosen the screw on the side of the tooling holder.  |

# TROUBLESHOOTING GUIDE (CONT'D)

| PROBLEM                            | CAUSE   | SOLUTION   |
|------------------------------------|---|--|
| Wheels unexpectedly engage         | Debris from wheel turns the coupling flange and re-engages the wheel. | Remove flange retaining screw, washer and spring. Clean debris that could be contacting the flange pins causing them to engage.  |
| while in neewneel mode.            | Missing or improperly installed wheel retaining ring                  | Remove flange retaining screw, washer and spring. Ensure retaining ring is present and fully seated.   |
| Machine is difficult to tilt back. | Slide weights are positioned forward.                                 | Before tilting machine back, position the slide weights rear-<br>ward to make tilting easier. Block up machine to prevent<br>machine from falling forward unexpectedly.      |
|                                    | Locking screws not sufficiently loosened                              | Loosen the four locking screws a few turns so screws clear<br>the locating posts. It is not necessary to remove screws.  |
| Can't remove front weight.         | Weight is binding with locating posts.                                | Pulling the weight forward during removal causes weight to<br>bind with the locating posts. See "MACHINE OPERATION"<br>section for the proper removal procedure.             |
| Can't remove middle weights.       | Locking screws not sufficiently loosened                              | Each middle weight is secured with two locking screws.<br>Loosen the locking screws a few turns so screws clear the<br>locating posts. It is not necessary to remove screws. |

## FAULT CODES

| FAULT BLINK CODE | DESCRIPTION                   | SOLUTION  |
|------------------|-------------------------------|---|
| 1                | Left VFD CAN communication    |   |
| 2                | Left VFD error active         |   |
| 3                | Right VFD CAN communication   |   |
| 4                | Right VFD error active        |   |
| 5                | Left control handle signal    |   |
| 6                | Right control handle signal   | Contact NFE technical services to further diagnose. |
| 7                | Max Speed pot signal          |   |
| 8                | Straight Trim pot signal      |   |
| 9                | Orbital VFD CAN communication |   |
| 10               | Orbital VFD error active      |   |
| 11               | Orbital Speed pot signal      |   |

### **OVERALL MACHINE**



#### NOTE:

• Part numbers with -X, -XXX and -XXXX suffixes indicate configurable items that are defined by the serial number of the machine. Contact NFE customer service for assistance.

# OVERALL MACHINE (CONT'D)

| Item No. | Part No.   | Description  | Qty. |
|----------|------------|--|------|
| 1        | 406633     | Assembly, Wheels, Transport, 1-1/4, Grooved              | 1    |
| 2        | 404863-XXX | Assembly, Handle, Rogue                                  | 1    |
| 3        | 405055-XXX | Assembly, Base, Scraper                                  | 1    |
| 4        | 405071-XXX | Installation, Drive Motors, Dual, Rogue                  | 1    |
| 5        | 405751     | Assembly, Tail, Base                                     | 1    |
| 6        | 405944-X   | Assembly, Weight, Front                                  | 1    |
| 7        | 406062     | Assembly, Slide Weight                                   | 2    |
| 8        | 406090     | Assembly, Weight, Middle                                 | 2    |
| 9        | 406684     | Lifting Bar  | 1    |
| 10       | 406685-X   | Body Panels  | 1    |
| 11       | 406686     | Wheel Scraper, Bi-directional                            | 2    |
| 12       | 406687     | Cover, Bottom  | 1    |
| 13       | 404281     | Screw, Button Head Cap, M10-1.5x20, Flanged, Clear Zinc  | 4    |
| 14       | 406778     | Bolt, Wizlock, M8-1.25x16, Clear Zinc, Class 8.8         | 6    |
| 15*      | 406994     | Label, Template, CE, 1 x 3, Battery or Plug In, with IPX | 1    |
| 16*      | 407221     | Label, QR Code, Manuals, 3x1.5"                          | 1    |
| 17*      | 408027     | Kit, Pole, Transport (Optional)                          | 1    |

\*Not shown

#### POWER CORD 407141-XXXX

| Part No.    | Region              | Description                                     |
|-------------|---------------------|---|
| 407141-04AU | Australia           | Cord, Power, C19, AS3112, 16/3, 10ft, Australia |
| 407141-14JP | Japan               | Cord, Power, C19, JIS C 8303, 14/3, 10ft, Japan |
| 407141-13US | North America       | Cord, Power, C19, NEMA 5-15P, 14/3, 8ft, US     |
| 407141-03EU | Europe              | Cord, Power, C19, CEE7/7, 16/3, 8ft, Europe     |
| 407141-23UK | United Kingdom (UK) | Cord, Power, C19, IEC 309 (4H), 12/3, 8ft, UK   |

## SCRAPER BASE ASSEMBLY 405055-XXX



| Item No. | Part No.   | Description                                      | Qty. |
|----------|------------|--|------|
| 1        | 401349     | Washer, Fender, M8, Clear Zinc                   | 2    |
| 2        | 401509     | Nut, Hex, Nylon Insert, M8-1.25, Clear Zinc      | 2    |
| 3        | 404702     | Base, Frame                                      | 1    |
| 4        | 405056     | Install, Cutting Head                            | 1    |
| 5        | 405057-XXX | Installation, Orbital Motor, Rogue               | 1    |
| 6        | 406778     | Bolt, Wizlock, M8-1.25x16, Clear Zinc, Class 8.8 | 12   |
| 7        | 406798     | Post, Mounting, Weight                           | 8    |
| 8        | 406845     | Bracket, Mount, Panel, Body                      | 2    |
| 9        | 406872     | Pad, Middle Weight, Adh                          | 2    |
| 10       | 406876     | Pad, Front Weight, LH, Adh                       | 1    |
| 11       | 406924     | Pad, Front Weight, RH, Adh                       | 1    |
| 12       | 407009     | Spacer, Round, .322 x .472 x .236, Nylon         | 2    |

## **ORBITAL MOTOR ASSEMBLY 405057-XXX**



| Item No. | Part No.   | Description  | Qty. |
|----------|------------|--|------|
| 1        | 402240     | Nut, Hex, Nylon Insert, M10-1.5, Heavy, Clear Zinc | 4    |
| 2        | 407353     | Subassy, Bearing/Eccentric                         | 1    |
| 3        | 406689-XXX | Motor/VFD, Wired/Programmed, Orbital               | 1    |
| 3.1      | 406875     | Pad, Foam, 3/8 x 1-1/4, PVC/Neoprene, Adh          | 2    |
| 3.5      | 406574     | Label, Pictogram, Electrical Hazard                | 1    |
| 4        | 406808     | Guide, Cable, Actuator                             | 1    |
| 5        | 74651      | Bolt, Wizlock, M10-1.5 x 30mm, Class 8.8           | 4    |

## ECCENTRIC ASSEMBLY 407353



| Item No. | Part No. | Description  | Qty. |
|----------|----------|--|------|
| 1        | 404785   | Eccentric, Cutting Head                                  | 1    |
| 2        | 406688   | Subassy, Bearing/Housing                                 | 1    |
| 3        | 406094   | Ring, Retaining, External, Axial, 30mm, Heavy, Phosphate | 1    |
| 4        | 406093   | O-ring, 1.301 x 1.441 x .070, Buna-N, 70A                | 1    |

## **CUTTING HEAD ASSEMBLY 405056**



| Item No. | Part No. | Description  | Qty. |
|----------|----------|--|------|
| 1        | 401516   | Nut, Hex, Nylon Insert, M6-1.0, Clear Zinc         | 2    |
| 2        | 405143   | Deflector Weldment, Tool Holder                    | 1    |
| 3        | 405922   | Isolator, 3-piece, 2" x 3-1/2", 70A                | 4    |
| 4        | 406087   | Screw, Hex Head Cap, 1/2-13x4-1/2, Clear Zinc      | 4    |
| 5        | 406088   | Washer, Flat, 1/2 x 1-3/4, Clear Zinc              | 4    |
| 6        | 406110   | Label, Warning, No Step/Team Lift                  | 1    |
| 7        | 406666   | Bolt, Carriage, M6-1.0 x 16, Clear Zinc            | 2    |
| 8        | 407124   | Label, Warning, Hot Surface/Pinch/Sharp Edge       | 1    |
| 9        | 73402    | Nut, Nylock, 1/2-13                                | 4    |
| 10       | 406011   | Bolt, Wizlock, M8-1.25 x 20, Clear Zinc, Class 8.8 | 3    |
| 11       | 407359   | Actuator/Linkage Assembly, Tool Holder             | 1    |
| 12       | 407363   | Subassy, Plate-Bearing, Cutting Head               | 1    |

## ACTUATOR/LINKAGE ASSEMBLY 407359



## ACTUATOR/LINKAGE ASSEMBLY 407359 (CONT'D)

| Item No. | Part No. | Description  | Qty. |
|----------|----------|--|------|
| 1        | 401509   | Nut, Hex, Nylon Insert, M8-1.25, Clear Zinc                  | 1    |
| 2        | 404999   | Tab Wldt, Release, Lock, Tooling                             | 1    |
| 3        | 407364   | Subassy, Bracket with Pads, Cutting Head                     | 1    |
| 4        | 405618   | Screw, Button Head Cap, Flanged, M4-0.7x6, Clear Zinc, Patch | 2    |
| 5        | 405619   | Spring, Compression, .210 x .250 x .022, Music Wire          | 1    |
| 6        | 406011   | Bolt, Wizlock, M8-1.25 x 20, Clear Zinc, Class 8.8           | 3    |
| 7        | 406084   | Boot, Bottom, Actuator Mount, Adh                            | 1    |
| 8        | 406089   | Assy, Actuator, Linear, 24VDC, 100mm, 5kN                    | 1    |
| 9        | 407414   | Subassy, Mount, Riser  | 1    |
| 10       | 407045   | Spacer, Round, .500 x .316 x 1.288                           | 1    |
| 11       | 407093   | Bolt, Shoulder, 1/2 x 2 x 3/8-16, Alloy                      | 1    |
| 12       | 407094   | Screw, Socket Head Cap, M8-1.25x65, Black Oxide              | 1    |
| 13       | 407150   | Screw, Socket Head Cap, M8x1.25x16, Trilobe, Clear Zinc      | 1    |
| 14       | 407360   | Linkage Subassembly, Tool Holder                             | 1    |
| 15       | 73207    | Nut, Hex, Nylon Insert, 3/8-16                               | 1    |
| 16       | 407362   | Pin, Pivot, .500 X 2.038                                     | 1    |
| 17       | 407409   | Pin, Pivot, .500 x 2.918                                     | 1    |
| 18       | 407412   | Fitting, Grease, Straight, M5                                | 3    |
| 19       | 407405   | Pin, Spring, 3/32 x 1-1/4, Plain                             | 4    |
| 20       | 402197   | O-ring, .489 ID X .629 OD X .070 W                           | 4    |
| 21       | 407413   | Fitting, Grease, 45, M8                                      | 1    |

### **BRACKET ASSEMBLY 407364**



| Item No. | Part No. | Description                                   | Qty. |
|----------|----------|---|------|
| 1        | 405227   | Weldment, Mount, Actuator, LA33               | 1    |
| 2        | 406890   | Pad, Foam, 1/4 x 1 x 6, PVC/Neoprene, Adh     | 1    |
| 3        | 406891   | Pad, Foam, 3/8 x 1-1/4 x 4, PVC/Neoprene, Adh | 3    |
| 4        | 407100   | Pad, Foam, 1/2 x 2-3/4 x 2-3/4, Adh           | 2    |
| 5        | 407101   | Pad, Foam, 1/2 x 1-3/4 x 7, Adh               | 1    |
| 6        | 407103   | Liner, Wear, Actuator, 2-1/2 x 2-1/2, Adh     | 1    |
| 7        | 407104   | Liner, Wear, Actuator, 1-5/8 x 6, Adh         | 1    |
| 8        | 407128   | Liner, Wear, Actuator, 2-5/8 x 4-1/2, Adh     | 1    |

## **CUTTING HEAD PLATE 407363**



| Item No. | Part No. | Description                                     | Qty. |
|----------|----------|---|------|
| 1        | 404705   | Plate, Cutting Head                             | 1    |
| 2        | 405624   | Screw, Socket Head Cap, M10-1.5x30, Black Oxide | 2    |
| 3        | 71131    | Bearing 1-1/4 ID, SBLF 206-20                   | 1    |
| 4        | 74656    | Nut, Hex, Nylon Insert, M10-1.5, Clear Zinc     | 2    |

## DUAL DRIVE MOTORS ASSEMBLY 405071-XXX



| Item No. | Part No.   | Description  | Qty. |
|----------|------------|--|------|
| 1        | 404711     | Strap, Frame, Axle Gap                                 | 2    |
| 2        | 405042     | Assembly, Flange, Locking, Wheel                       | 2    |
| 3        | 405046     | Washer, Fender, 5/16 x 1-1/4, Clear Zinc               | 2    |
| 4        | 405074     | Spring, Compression, Tapered, 1.28/1.03 x .89L x .067w | 2    |
| 5        | 406778     | Bolt, Wizlock, M8-1.25x16, Clear Zinc, Class 8.8       | 12   |
| 6        | 406096     | Screw, Torx Button Head Cap, M8x1.25 x 12, Clear Zinc  | 2    |
| 7        | 407147-XXX | Assembly, Drive Motor, RH                              | 1    |
| 8        | 407148-XXX | Assembly, Drive Motor, LH                              | 1    |
| 9        | 407367     | Shim, 1.000x1.500x.062, 1074 Steel                     | 4    |
| 10       | 407371     | Assembly, Wheel/Hub, Drive, 9"                         | 2    |
| 11       | 6280-103A  | Ring, Retaining, External, Axial, 1", Heavy, Phosphate | 2    |

## BOTTOM COVER 406687



| Item No. | Part No. | Description                           | Qty. |
|----------|----------|---------------------------------------|------|
| 1        | 407102   | Cover with Pads, Bottom, Frame        | 1    |
| 1.1      | 404712   | Cover, Bottom, Frame                  | 1    |
| 1.2      | 407096   | Pad, Rubber, 1/8 x 1-1/2 x 1-1/2, Adh | 4    |
| 2        | 74636    | Bolt, Wizlock, M6-1.0x16, Clear Zinc  | 4    |

## TAIL ASSEMBLY 405751



# TAIL ASSEMBLY 405751 (CONT'D)

| Item No. | Part No.   | Description   | Qty. |
|----------|------------|---|------|
| 1        | 404995     | Weldment, Tail, Base                                    | 1    |
| 2        | 405251     | Assembly, Panel, Distribution, Power                    | 1    |
| 3        | 405304     | Cover, Elec, Tail                                       | 1    |
| 4        | 404906     | Lock Nut, M32, Black Nylon                              | 1    |
| 5        | 406101     | Circuit Breaker, Panel Mount, 1P, 15A                   | 1    |
| 6        | 407022     | Seal, Button, Nut, 3/8-27                               | 1    |
| 7        | 407008     | Screw, Torx Flat Head Socket Cap, M3-0.5x10, Clear Zinc | 2    |
| 8        | 407001     | Bezel, Box, Elec, LH                                    | 1    |
| 9        | 407002     | Bezel, Box, Elec, RH                                    | 1    |
| 10       | 403235     | Nut, Keps, M6-1.0, Clear Zinc                           | 10   |
| 11       | 406821     | Strain Relief, M32, Black Nylon, 14-25mm ID             | 1    |
| 12       | 407003     | Isolator, Vibration, 1 x 1/2, M/F, M6                   | 4    |
| 13       | 407083     | Screw, Torx Pan Head, M5-0.8x12, Clear Zinc             | 6    |
| 14       | 407088     | Plug, Panel, Round, 2-1/2, Vinyl                        | 1    |
| 15       | 407024     | Gasket, 1/16 x 1/2 x 20, PVC/Neoprene, Adh              | 1    |
| 16       | 407089     | Gasket, Foam, LH, Tail, Adh                             | 1    |
| 17       | 407090     | Gasket, Foam, RH, Tail, Adh                             | 1    |
| 18       | 406574     | Label, Pictogram, Electrical Hazard                     | 1    |
| 19       | 407135-060 | Plug, Mate-N-Lok Series, 6P                             | 3    |
| 20       | 407379     | Harness, Power, Rogue                                   | 1    |
| 21       | 407378     | Inlet, IEC-C20, Enhanced Filter, 20A, 1/4" QCs          | 1    |
| 22       | 407135-020 | Plug, Mate-N-Lok Series, 2P                             | 1    |

## POWER DISTRIBUTION PANEL ASSEMBLY 405251



| Item No. | Part No. | Description                                   | Qty. |
|----------|----------|---|------|
| 1        | 405303   | Panel, Elec, Tail                             | 1    |
| 2        | 405783   | End Stop, DIN Rail, 35mm, Slim                | 3    |
| 3        | 406005   | Washer, Lock, Ext Tooth, M5, Clear Zinc       | 2    |
| 4        | 406044   | Power Supply, 24VDC, 90-264VAC, 350W, Slim    | 1    |
| 5        | 406099   | Screw, Socket Head Cap, M3X0.5X6, Black Oxide | 4    |
| 6        | 406100   | Harness, Base, Rogue                          | 1    |
| 7        | 406102   | Relay, 25A, 24VDC, DPST                       | 1    |
| 8        | 407006   | RCCB, Rail Mount, 2P, 30mA                    | 1    |
| 9        | 407007   | DIN Rail, 35mm x 3-1/2                        | 1    |
| 10       | 407083   | Screw, Torx Pan Head, M5-0.8x12, Clear Zinc   | 2    |
| 11       | 401653   | Screw, Socket Head Cap, M4-0.7 x 12           | 2    |
| 12       | 402258   | Nut, Keps, M5-0.8, Clear Zinc                 | 1    |
| 13       | 403086   | Label, Ground                                 | 1    |

## LIFTING BAR 406684



| Item No. | Part No. | Description  | Qty.  |
|----------|----------|--|-------|
| 1        | 406011   | Bolt, Wizlock, M8-1.25 x 20, Clear Zinc, Class 8.8 | 8     |
| 2        | 406846   | Leg, Eyelet, Lift                                  | 2     |
| 3        | 406847   | Brace, Cross, Eyelet, Lift                         | 1     |
| 4        | 406879   | Strip, Foam, 1/16 x 1/2, PVC/Neoprene, Adh         | 9" 2X |

#### HANDLE ASSEMBLY 404863-XXX



HANDLE ASSEMBLY 404863-XXX (CONT'D)



## HANDLE ASSEMBLY 404863-XXX (CONT'D)



## HANDLE ASSEMBLY 404863-XXX (CONT'D)



## HANDLE ASSEMBLY 404863-XXX (CONT'D)

| Item No. | Part No.   | Description   | Qty. |
|----------|------------|---|------|
| 1        | 401327     | Washer, Flat, M5, Clear Zinc                            | 2    |
| 2        | 401516     | Nut, Hex, Nylon Insert, M6-1.0, Clear Zinc              | 1    |
| 3        | 401652     | Screw, Socket Head Cap, M6-1.0 x 12, Black Oxide        | 1    |
| 4        | 401658     | Screw, Socket Head Cap, M5-0.8 x 12, Black Oxide        | 12   |
| 5        | 402258     | Nut, Keps, M5-0.8, Clear Zinc                           | 5    |
| 6        | 403086     | Label, Ground   | 1    |
| 7        | 403253     | Meter, Hour, Digital, 20-300VAC, 10-300VDC, Snap-on     | 1    |
| 8        | 404281     | Screw, Button Head Cap, M10-1.5x20, Flanged, Clear Zinc | 6    |
| 9        | 404807     | Weldment, Control Box                                   | 1    |
| 10       | 404810     | Assembly, Wedge Pin, Stop                               | 1    |
| 11       | 404813     | Disk, Take-Up, Hub, Keyed                               | 1    |
| 12       | 404814     | Weldment, Shaft/Disk, Pivot                             | 1    |
| 13       | 404815     | Disk, Index, Fixed                                      | 4    |
| 14       | 404850     | Screw, Set, Flat, M6x1.0 x 6mm Long                     | 4    |
| 15       | 404984     | Guide, Rod, Upper, Handle                               | 1    |
| 16       | 404990     | Weldment, Lever, Release, Handle                        | 1    |
| 17       | 405125     | Washer, Shim, .625 x 1.00 x .125, Steel                 | 1    |
| 18       | 405759     | Handle, Control, Ministro, Black/Gray                   | 2    |
| 19       | 406051     | Panel, Access, Handle, Upper                            | 1    |
| 20       | 406055     | Block, Bearing, Pivot, Handle                           | 2    |
| 21       | 406066     | Knob, Potentiometer, 1/4" with Set Screw                | 2    |
| 22       | 406067     | Wire Harness, Controls, Rogue                           | 1    |
| 23       | 406068     | Spring, Compression, .75 x 2.00 x .080, MW              | 1    |
| 24       | 406070     | Clamp, Loop, 1/4 Dia, 3/8 Wide, Stainless Steel         | 2    |
| 25       | 406071     | Key, Rounded, 1/4 x 1/4 x 1-1/4                         | 1    |
| 26       | 406072     | Key, Square, 1/4 x 1/4 x 5/8                            | 1    |
| 27       | 406074     | Switch, Rocker  | 1    |
| 28       | 406108     | Label, Logo, Front                                      | 1    |
| 29       | 406109     | Label, Control Panel                                    | 1    |
| 30       | 406203     | Harness, Handle, Rogue                                  | 1    |
| 31       | 406581     | Label, Pictogram, Inhalation Hazard                     | 1    |
| 32       | 406603     | Label, ISO Pictograms, 4 x 5.5"                         | 1    |
| 33       | 406620     | Weldment, Base, Handle, Lower                           | 1    |
| 34       | 406773     | Switch, SPST, Panel Mount, 30V, 10A                     | 1    |
| 35       | 406774     | Relay, Micro, SPDT, 24VDC, 20A                          | 2    |
| 36       | 406775     | Kit, Start/Stop Switch, 22mm, Illuminated               | 1    |
| 37       | 407475-XXX | Controller, HFX20M, Programmed                          | 1    |
| 38       | 406878     | Pad, Rubber, Handle/Transport, Adh                      | 1    |
| 39       | 406884     | Cover with Gasket, Control Panel, Upper                 | 1    |
| 40       | 407084     | Screw, Torx Pan Head, M4-0.7x12, Trilobular, Clear Zinc | 12   |
### HANDLE ASSEMBLY 404863-XXX (CONT'D)

| Item No. | Part No.  | Description                          | Qty. |
|----------|-----------|--------------------------------------|------|
| 41       | 407085    | Assembly, Kill Switch, Tether        | 1    |
| 42       | 407125    | Label, Pictogram, Pinch Point        | 1    |
| 43       | 407142    | Assy, Indicator, LED, 24VDC, 14mm    | 1    |
| 44       | 407152    | Phantom, E-Stop Switch, Triple       | 1    |
| 45       | 407237    | Cover, Lower, Handle                 | 1    |
| 46       | 5280-137W | Wrench, Blade, 6mm                   | 1    |
| 47       | 63-P30    | Clamp, Wire 3/8                      | 1    |
| 48       | 63-P31    | Clamp, Wire, 3/4                     | 2    |
| 49       | 72873     | Clamp, Cable, Vinyl Coated, 3/8      | 2    |
| 50       | 73092     | Washer, Flat USS Zinc 1/4            | 1    |
| 51       | 74636     | Bolt, Wizlock, M6-1.0x16, Clear Zinc | 4    |

# PARTS LISTS

### HOOD 406685-X



| Item No. | Part No. | Description                                      | Qty. |
|----------|----------|--|------|
| 1        | 405139   | Spacer, Block, Side Panel                        | 4    |
| 2        | 405140   | Rod, Side Body                                   | 2    |
| 3        | 405755   | Bolt, Wizlock, M8-1.25x30, Clear Zinc, Class 8.8 | 8    |
| 4        | 406778   | Bolt, Wizlock, M8-1.25x16, Clear Zinc, Class 8.8 | 8    |
| 5        | 406844-X | Weldment, Panel, Body, Silver Vein               | 1    |

### FRONT WEIGHT 405944-X



| Item No. | Part No. | Description   | Qty. |
|----------|----------|---|------|
| 1        | 404730-X | Subassembly, Front Weight                               | 1    |
| 2        | 406107   | Label, National Logo, 4.12 x 3.75                       | 1    |
| 3        | 406890   | Pad, Foam, 1/4 x 1 x 6, PVC/Neoprene, Adh               | 2    |
| 4        | 407098   | Liner, Wear, Tab, Front Weight, Adh                     | 1    |
| 5        | 407099   | Liner, Wear, Side, Front Weight, Adh                    | 1    |
| 6        | 407149   | Screw, Socket Head Cap, M8x1.25x25, Trilobe, Clear Zinc | 4    |
| 7        | 407151   | Label, Team Lift, 31kg/68.3lb                           | 1    |

### MIDDLE WEIGHT 406090



| Item No. | Part No. | Description   | Qty. |
|----------|----------|---|------|
| 1        | 405517   | Weight, Middle, Rogue                                   | 1    |
| 2        | 407150   | Screw, Socket Head Cap, M8x1.25x16, Trilobe, Clear Zinc | 2    |

### SLIDE WEIGHT 406062



| Item No. | Part No. | Description   | Qty. |
|----------|----------|---|------|
| 1        | 405141   | Weight, Side, Slide                                     | 1    |
| 2        | 406107   | Label, Slide Weight                                     | 1    |
| 3        | 407149   | Screw, Socket Head Cap, M8x1.25x25, Trilobe, Clear Zinc | 2    |

### WHEEL SCRAPERS 406686





#### **LEFT-HAND CONFIGURATION**

#### **RIGHT-HAND CONFIGURATION**

| Item No. | Part No. | Description                                 | Qty. |
|----------|----------|---|------|
| 1        | 406629   | Cleaner, Wheel, Bidirectional               | 1    |
| 2        | 401509   | Nut, Hex, Nylon Insert, M8-1.25, Clear Zinc | 2    |

### **TRANSPORT WHEELS 406633**



| Item No. | Part No. | Description                   | Qty. |
|----------|----------|-------------------------------|------|
| 1        | 406637   | Weldment, Transport Wheels    | 1    |
| 2        | 6280-301 | Caster Assy, Swivel, 4", Stem | 2    |
| 3        | 73402    | Nut, Nylock, 1/2-13           | 2    |

### TRANSPORT POLE KIT (OPTIONAL) 408027



| Item No. | Part No. | Description                                  | Qty. |
|----------|----------|--|------|
| 1        | 406895   | Pin, Locking, Tube, 1-3/8 x 1/4, Yellow Zinc | 4    |
| 2        | 406896   | Subassy, Pole, Extension, Lifting            | 4    |



### PRIMARY SYSTEMS WIRING DIAGRAM







RESERVED



PAGE RESERVED











9250 Xylon Avenue N • Minneapolis, MN 55445 • U.S.A. Toll-free 800-245-0267 • Phone 763-315-5300 • Fax 800-648-7124 • Fax 763-535-8255 Web Site: www.nationalequipmentdirect.com • E-Mail: info@nationalequipment.com